

SUZUKI
RM

125



OWNER'S SERVICE MANUAL

This manual should be considered a permanent part of the motorcycle and should remain with the motorcycle when resold or otherwise transferred to a new owner or operator.

The manual contains important safety information and instructions which should be read carefully before operating the motorcycle.

SAMPLE

FOREWORD

This manual is presented as a means whereby you can maintain your RM125 in top working condition at all times. Your riding skill and the maintenance steps outlined in this manual will assure you of top performance from your machine under any type of competition.


We sincerely wish you and your Suzuki motorcycle a successful partnership for many years of happy riding.

All information, illustrations, photographs and specifications contained in the manual are based on the latest product information available at the time of publication. Due to improvements or other changes, there may be some discrepancies in this manual. Suzuki reserves the right to make production changes at any time, without notice and without incurring any obligation to make the same or similar changes to vehicles previous built or sold.

Suzuki Motor Corporation believes in conservation and protection of Earth's natural resources. To that end, we encourage every vehicle owner to recycle, trade in, or properly dispose of, as appropriate, used motor oil, engine coolant, and other fluid, and tires.

SUZUKI MOTOR CORPORATION

WARNING/CAUTION/NOTE

Please read this manual and follow its instructions carefully. To emphasize special information, the symbol  and the words WARNING, CAUTION and NOTE have special meanings. Pay special attention to the messages highlighted by these signal words:

WARNING

Indicates a potential hazard that could result in death or injury.

CAUTION

Indicates a potential hazard that could result in motorcycle damage.

NOTE:

Indicates special information to make maintenance easier or instructions clearer.

GENERAL CONSIDERATIONS

• **Wear a helmet and goggles**

A helmet is the most important piece of gear to wear. Helmets do not reduce essential vision or hearing. Generally, helmets do not cause or intensify injury if you crash. Helmets simply help your skull protect your intelligence, your memory, your personality, and your life.

Your eyesight is equally valuable. Wearing suitable eye protection can help keep your vision unblurred by the wind and help shield your eyes from branches and airborne matter like bugs, dirt, or pebbles kicked up by tires. Wear a helmet and eye protection every time you ride.

• **Wear protective gear**

Wear proper clothing when you ride. Avoid loose clothes or scarves, which could get caught in moving parts. Abrasion injuries can be minimized by wearing protective clothing including gloves, strong boots that fit over the ankle, long pants, and a long sleeve shirt or jackets. Experienced riders often wear a kidney belt and chest or back protector for additional comfort and protection.

• **Inspect your machine before riding**

Before each use, perform an inspection per "Periodic Inspection" section starting on page 2-3.

• **No Passengers**

Suzuki RMs are designed for the rider only.

• **Practice on level ground**

Before you begin riding, you should find a good place to practice the skills you need to ride safely. Find a flat, open area with enough space to maneuver. Check with your Suzuki dealer or call police department if you do not know where you can ride.

Review the controls on your motorcycle before riding.

• **Know your limits**

Always ride within the boundaries of your own skills. Knowing these limits and staying within them will help you avoid accidents. Ride only in events appropriate for your experience.

Safely competing on a motorcycle requires that your mental and physical skills are fully part of the experience. You should not attempt to operate a motor vehicle, especially one with two wheels, if you are tired or under the influence of alcohol or other drugs. Alcohol, illegal drugs, and even some prescription and over-the-counter drugs can cause drowsiness, loss of coordination, loss of balance, and loss of good judgment. If you are tired or under the influence of alcohol or other drugs, PLEASE DO NOT RIDE your motorcycle.

• **Conclusion.**

The actions of other riders are unpredictable. Your motorcycle's condition can change. These factors can best be dealt with by giving every ride your full attention.

Circumstances beyond your control could lead to an accident. You need to prepare for the unexpected by wearing a helmet and other protective gear, and practicing safe riding techniques to minimize the damage to you and your machine.

May all of your rides on your new Suzuki be winning rides!

SERIAL NUMBER LOCATION



The frame number ① is stamped on the steering head as shown in the photograph. The engine serial number ② is stamped on the right side of the crankcase assembly. Write down the serial numbers here for your future reference.

Frame No.	
-----------	--

Engine No.	
------------	--

SAMPLE

WARNINGS FOR SERVICING

▲ WARNING

Never run the engine indoors or in a garage. Exhaust gas contains carbon monoxide, a gas that is colorless and odorless and can cause death or severe injury.

Only run the engine outdoors where there is fresh air.



▲ WARNING

Fuel can catch on fire if you do not handle it properly. Gasoline vapors can catch fire easily.

Do not smoke when servicing the machine. Do not service the machine in an area where there are open flames or sparks.



▲ WARNING

Hot engine and muffler can burn you.

Wait until the engine and muffler cools before servicing.



▲ WARNING

Brake fluids and engine coolant can be hazardous to humans and pets. Brake fluid and engine coolant are harmful or fatal if swallowed, and harmful if it comes in contact with your skin or eyes.

Keep brake fluid and engine coolant away from children. Call your doctor immediately if swallowed, and induce vomiting. Flush eyes or skin with water if either brake fluid or engine coolant gets in eyes or comes in contact with skin.



▲ WARNING

Servicing the machine with engine running can be hazardous. You can be caught in the moving parts such as the drive chain, sprockets etc.

Be sure to stop the engine when servicing the machine.



▲ WARNING

Servicing the machine without proper clothes and protective gear can be hazardous. You can be injured if you do not wear proper clothes and protective gear.

Be sure to wear proper clothes and shoes for servicing and wear protective glasses, mask or gloves as necessary.



PRECAUTIONS FOR SERVICING

- Replace gaskets, snap rings, circlips, O-rings and cotter pins with new ones.
- Take care not to expand the end gap larger than required to slip the circlip over the shaft when installing a circlip.
- Use special tools where specified.
- Use genuine SUZUKI parts and recommended oil.
- When two or more persons work together, pay attention to the safety of each other.
- After reassembly, inspect parts for tightness and operation.

REPLACEMENT PARTS

Use only genuine SUZUKI replacement parts or their equivalent. Genuine SUZUKI parts are high quality parts which are designed and built specially for SUZUKI vehicles.

NOTE:

Use of replacement parts which are not equivalent in quality to genuine SUZUKI parts can lead to performance problems and damage.

SYMBOL MARKS AND MATERIALS

Listed in the table below are the symbols indicating instructions and other information. The meaning of each symbol is also included in the table.

SYMBOL	DEFINITION	SYMBOL	DEFINITION
	Torque control required. Data beside it indicates specified torque.		Use SUZUKI REAR SUSPENSION OIL SS-25 or equivalent rear suspension oil. 99000-99001-SS25
	Apply oil. Use engine oil or transmission oil unless otherwise specified.		Use engine coolant.
	Apply SUZUKI SUPER GREASE "A". 99000-25030 (USA) 99000-25010 (Others)		Apply or use brake fluid. (DOT4)
	Apply SUZUKI SILICONE GREASE. 99000-25100		Measure in voltage range.
	Apply SUZUKI BOND "1207B". 99104-31140 (USA) 99000-31140 (Others)		Measure in resistance range.
	Apply THREAD LOCK SUPER "1303". 99000-32030		Measure in diode test range.
	Apply THREAD LOCK SUPER "1322". 99000-32110 (Except USA)		Use special tool.
	Apply THREAD LOCK "1342". 99000-32050		Indication of service data.
	Apply THREAD LOCK SUPER "1380". 99000-32130		Replace a part with a new one when reassembling.
	Use SUZUKI FORK OIL SS-05 or equivalent fork oil. 99000-99001-SS5		

GROUP INDEX

<i>GENERAL INSTRUCTIONS</i>	1
<i>PERIODIC MAINTENANCE</i>	2
<i>TROUBLESHOOTING</i>	3
<i>MACHINE TUNING</i>	4
<i>ENGINE REMOVAL AND INSTALLATION</i>	5
<i>CYLINDER, PISTON AND EXHAUST VALVE</i>	6
<i>CLUTCH</i>	7
<i>KICK STARTER</i>	8
<i>GEARSHIFTING</i>	9
<i>TRANSMISSION AND CRANKSHAFT</i>	10
<i>FUEL SYSTEM</i>	11
<i>COOLING SYSTEM</i>	12
<i>ELECTRICAL SYSTEM</i>	13
<i>FRONT AND REAR WHEELS</i>	14
<i>FRONT AND REAR BRAKES</i>	15
<i>FRONT FORK AND STEERING</i>	16
<i>REAR SUSPENSION</i>	17
<i>SERVICING INFORMATION</i>	18

GENERAL INSTRUCTIONS

1

CONTENTS


LOCATION OF PARTS	1- 2
FUEL AND OIL RECOMMENDATION	1- 3
OPERATING INSTRUCTIONS	1- 4
STARTING THE ENGINE	1- 4
STOPPING THE ENGINE	1- 4
TRANSMISSION	1- 5
BREAK-IN (RUNNING-IN)	1- 5
WHEN THE MOTORCYCLE IS NEW	1- 5
WHEN ENGINE PARTS ARE REPLACED	1- 5
COUNTRY AND AREA CODES	1- 6

SAMPLE

LOCATION OF PARTS



- ① Clutch lever
- ② Engine stop switch
- ③ Front brake fluid reservoir
- ④ Throttle grip
- ⑤ Front brake lever



- ⑥ Fuel tank cap
- ⑦ Fuel valve
- ⑧ Carburetor starter knob
- ⑨ Gearshift lever



- ⑩ Rear brake fluid reservoir
- ⑪ Rear brake pedal
- ⑫ Kick starter lever
- ⑬ Front suspension compression damping adjuster
- ⑭ Front suspension rebound damping adjuster
- ⑮ Rear suspension compression damping adjuster
- ⑯ Rear suspension rebound damping adjuster

FUEL AND OIL RECOMMENDATION

This motorcycle is of the two-stroke design, which requires a premixture of gasoline and oil.

Gasoline: Use only unleaded gasoline of at least 90 pump octane (R/2 + M/2 method) For USA and Canada
Use only unleaded gasoline of at least 95 octane (Research method) For other countries.

Engine oil: SUZUKI OGI SUPER 2-CYCLE MOTOR LUBRICANT or equivalent Two Cycle Racing Lubricant For USA

MOTUL 800 2T FACTORY LINE OFF ROAD
or equivalent Two Cycle Racing Lubricant

..... For other countries

Mixing ratio: 30 : 1

Fuel tank capacity: 8.3 L (2.071.6 US/imp gal)



CAUTION

A mixture containing too little oil will cause piston seizure. Too much oil will cause excessive carbon formation resulting in preignition, fouled spark plug and loss of engine power.

Mix fuel and the engine oil at the ratio of 30:1.

NOTE:

- * Mix gasoline and the engine oil thoroughly when the temperature is below 0 °C (32 °F). Vegetable-based oils can separate easier than mineral oils.
- * Use premixture oil as soon as possible after mixing, or lubrication performance of the engine oil can decrease.
- * Do not mix vegetable-based oil and mineral oil.
- * Insert the end of the breather hose into the steering stem head after refueling.

Gasoline (L)	Oil (ml)	Gasoline (US gal.)	Oil (US oz.)	Gasoline (imp gal.)	Oil (imp oz.)
5.0	167	1	4.3	1	5.4
10.0	333	2	8.6	2	10.7
15.0	500	3	12.8	3	16.0
20.0	667	4	17.1	4	21.4

OPERATING INSTRUCTIONS

STARTING THE ENGINE

Inspect the transmission oil level, coolant level and air cleaner condition before starting the engine.

When the engine is cold:


- 1) Turn the fuel valve lever to the "ON" position.
- 2) Shift the transmission into neutral.
- 3) Pull the starter knob ①.
- 4) Close the throttle grip completely and depress the kick starter lever forcefully.
- 5) Return the starter knob when the engine revs at steady speed.

When the engine is warm:

- 1) Turn the fuel valve lever to the "ON" position.
- 2) Shift the transmission into neutral.
- 3) Open the throttle 1/8 - 1/4 turn and depress the kick starter lever forcefully.

To restart after the motorcycle has fallen:

- 1) Shift the transmission into neutral.
- 2) Open the throttle completely and depress the kick starter lever forcefully.
- 3) Close the throttle gradually as engine speed increases.
- 4) Wait until engine revs smoothly.



CAUTION
<p>Racing the engine in neutral will exceed the engine speed limit. Exceeding the engine speed limit can damage the engine moving parts.</p> <p>Do not race the engine at high speed to avoid the engine damage.</p>



STOPPING THE ENGINE

- 1) Shift the transmission into neutral.
- 2) Turn the fuel valve lever to the "OFF" position.
- 3) Push the engine stop switch ① to stop the engine.

▲ WARNING


Leaving the fuel valve in the "ON" position may cause carburetor overflow. This can cause a fire or severe engine damage when you start the engine.

Always leave the fuel valve in the "OFF" position when the engine is not running.



TRANSMISSION

This motorcycle has a 6-speed transmission. Neutral is located between low and 2nd. Engage first gear by pressing the lever down from the neutral position. You can shift into higher gears by lifting on the shift lever once for each gear. When neutral is desired, press or lift the lever to a position halfway between low and 2nd gear.




BREAK-IN (RUNNING-IN) WHEN THE MOTORCYCLE IS NEW

- 1) Warm up the engine before starting off.
- 2) Ride for 60 minutes using less than 1/2 throttle opening.
- 3) Ride for 60 minutes using less than 3/4 throttle opening.

NOTE:

- * The break in (running-in) period is the period of greatest wear.
- * The bolts and nuts of the new machine can loosen quickly. Be sure to retighten the bolts and nuts during the break-in (running-in) period.



WHEN ENGINE PARTS ARE REPLACED

Follow the same procedure when any of the following parts are replaced:

- Piston
- Piston ring
- Cylinder
- Crankshaft
- Crankshaft bearing

COUNTRY AND AREA CODES

The following codes stand for the applicable country(-ies) and area(-s).

CODE	COUNTRY or AREA
E-03	U. S. A.
E-28	Canada
000	Japan

SAMPLE

Service Item	Interval	Every race	Every 3 races	Every 5 races	Remarks
	hours	Every 2 hours	Every 6 hours	Every 10 hours	
Tire		I	—	—	
Spoke nipple		I	—	—	Inspect every 20 min. up to initial 2 hours then check before each ride.
Steering		I	—	—	
Bolts and nuts		T	—	—	Retighten every 1 hour.

NOTE: R = Replace, C = Clean, T = Tighten, I = Inspect and clean, adjust lubricate or replace if necessary.
L = Lubricate

SAMPLE

PERIODIC MAINTENANCE

CONTENTS

PERIODIC MAINTENANCE	2- 3
INSPECTION BEFORE PRACTICE	2- 3
INSPECTION BEFORE RACE	2- 3
PERIODIC MAINTENANCE CHART	2- 4
SPARK PLUG	2- 6
AIR CLEANER	2- 7
AIR CLEANER ELEMENT REMOVAL	2- 7
WASHING	2- 7
INSTALLATION	2- 7
TRANSMISSION OIL	2- 8
TRANSMISSION OIL LEVEL INSPECTION AND REPLENISHMENT	2- 9
TRANSMISSION OIL CHANGE	2- 9
ENGINE COOLANT	2-10
ENGINE COOLANT LEVEL CHECK	2-10
ENGINE COOLANT REPLENISHMENT	2-11
COOLING SYSTEM INSPECTION	2-11
CLUTCH CABLE	2-12
MAJOR ADJUSTMENT	2-12
MINOR ADJUSTMENT	2-12
THROTTLE CABLE	2-12
FUEL HOSE	2-13
FUEL VALVE	2-13
CYLINDER HEAD, CYLINDER AND PISTON	2-14
CYLINDER HEAD	2-14
CYLINDER	2-14
PISTON	2-14
EXHAUST VALVE	2-15
EXHAUST SILENCER	2-15
SILENCER INSPECTION AND REPLACEMENT	2-15
SILENCER REASSEMBLY	2-15
DRIVE CHAIN AND SPROCKETS	2-16
DRIVE CHAIN SLACK	2-16
DRIVE CHAIN ADJUSTMENT	2-16
20TH PITCH LENGTH	2-16
DRIVE CHAIN LUBRICATION	2-16
SPROCKET INSPECTION	2-17
DRIVE CHAIN GUIDE, BUFFER, TENSIONER ROLLER	2-17

PERIODIC MAINTENANCE

CONTENTS

DRIVE CHAIN GUIDE	2-17
DRIVE CHAIN GUIDE BUFFER	2-18
DRIVE CHAIN TENSIONER ROLLER	2-18
BRAKES	2-18
BRAKE FLUID LEVEL	2-18
BRAKE PAD	2-19
FRONT BRAKE LEVER ADJUSTMENT	2-19
BRAKE PEDAL HEIGHT ADJUSTMENT	2-19
FRONT FORK	2-20
REAR SUSPENSION	2-20
WHEELS AND TIRES	2-20
WHEEL RIM	2-20
SPOKE NIPPLE AND RIM LOCK	2-21
TIRE PRESSURE	2-21
STEERING	2-21
LUBRICATION	2-22
TIGHTENING TORQUE	2-23

PERIODIC MAINTENANCE INSPECTION BEFORE PRACTICE

WHAT TO CHECK	CHECK FOR
Spark plug	<ul style="list-style-type: none"> Heat range, fouled electrode, tightness Loose high-tension cord
Air cleaner element	Lubrication
Transmission oil	Oil level
Coolant	Coolant level
Cooling system	<ul style="list-style-type: none"> Radiator hose damage Engine coolant leak
Clutch	<ul style="list-style-type: none"> Play Smooth operation
Throttle	<ul style="list-style-type: none"> Play Smooth operation
Brake fluid	Fluid level
Brakes	<ul style="list-style-type: none"> Brake lever position Brake pedal height Operation
Drive chain	Slick, lubrication, chain joint clip condition
Drive chain guide/buffer	Wear, damage
Suspension	<ul style="list-style-type: none"> Smooth operation Front fork air pressure
Wheels	<ul style="list-style-type: none"> Spoke tension Rim lock tightness
Tires	Tire pressure
Steering	Smoothness, play
Exhaust pipe	Firm fixation
Bolts and nuts	Tightening torque

INSPECTION BEFORE RACE

WHAT TO CHECK	CHECK FOR
All items of inspection before practice above plus	
Air cleaner	Cleanliness
Clutch	Clutch disc plates wear and distortion
Brake pads	Wear
Sprockets	Wear
Fuel tank	<ul style="list-style-type: none"> Leakage Fuel filter clogging
Fuel hose	Damage
Exhaust pipe	Damage
Piston and Cylinder	<ul style="list-style-type: none"> Combustion chamber carbon deposit Piston head carbon deposit Piston and cylinder wear
Suspension	<ul style="list-style-type: none"> Smooth operation Front fork air pressure

PERIODIC MAINTENANCE CHART

It is very important to inspect and maintain the machine regularly. Follow the guideline in the chart. The life of parts varies depending on the riding conditions. Perform more often than shown in the chart if you use the motorcycle under severe conditions.

Service Item	Interval		Every 3 races Every 6 hours	Every 5 races Every 10 hours	Remarks
	rides	hours			
Spark plug	I		R	—	
Air cleaner		C	—	—	Replace air cleaner element as necessary.
Transmission oil		—	R	—	Change after 1st initial break-in.
Cooling system	I		—	—	Replace radiator hose and engine coolant every year. Flushing for overhaul or storage.
Clutch	I		—	—	Replace clutch plates as necessary.
Throttle cable and clutch cable	I & L		—	—	
Carburetor	I		—	—	
Fuel hose	I		—	—	Replace every 4 years.
Piston	—		—	R	
Piston ring	—		R	—	
Cylinder head, cylinder	—		C	—	
Exhaust valve	—		C	—	
Crankshaft and transmission bearing			Inspect as required		
Muffler			—	—	
Drive chain	I & L		R	—	Adjust slack every 30 minutes.
Engine sprocket	I		—	—	
Rear sprocket	I		—	—	Check and retighten sprocket bolts at initial and subsequent 10 minutes of riding and each race thereafter.
Drive chain buffer	—		R	—	
Drive chain guide	—		R	—	
Kick starter lever	I & L		—	—	
Brake	I		—	—	Replace brake hose and fluid every year.
Front fork oil	—		R	—	Change after 1st initial break-in.
Front fork	I		—	—	Check front fork inner tube frequently for abnormality. Check the air pressure.
Rear suspension system pivoting portion	I		—	—	Check rear suspension system frequently and apply the grease to the pivoting portion as necessary.

Jet needle

Air/fuel mixture	SIZE	P/NO
Lean ↑ ↓ Rich	6CHY17-64	13383-36FM0
	6CHY16-64	13383-36FL0
	6CHY17-63	13383-36FP0
	6CHY16-63	13383-36FN0
	6CHY17-62	13383-36FR0
	6CHY16-62	13383-36FO0
	6CHY17-61	13381-36F00
	6CHY16-61	13383-36FS0
	6CHY17-60	13381-36F20
	6CHY16-60	13381-36F10

NOTE:

SHADED: STANDARD

↑: INCLUDED ALTERNATE PARTS

NONE: OPTIONAL PARTS

① Adjustment of pilot system

- 1) Set the air screw as specified.
- 2) See if the selected pilot jet is correct or not by judging the air/fuel mixture. If air/fuel mixture is rich, replace it with smaller one. If air/fuel mixture is lean, replace it with larger one.

Ex. Pilot jet #42.5

If air/fuel mixture is rich, replace it with #40 pilot jet. If air/fuel mixture is lean, replace it with #45 slow jet.

② Adjustment of main system


With the throttle opened 3/4 to full, make main system adjustment monitoring the air/fuel mixture condition after completion of pilot system settings.

* Make sure to adjust the main system before adjusting the intermediate system.

Ex. Main jet #460

If air/fuel mixture is rich, replace it with #450 main jet. If air/fuel mixture is lean, replace it with #470 main jet.

③ Adjustment of intermediate system




Monitor the air/fuel mixture condition and adjust the intermediate system by changing the needle clip position or cable holder (①②③④⑤).

④ Fine adjustment of slow system

After a proper setting has been obtained by the procedure ① through ③, fine tune the carburetor according to the actual race conditions.

- 1) Adjust the air/fuel mixture by turning the air screw within 1/2 – 2 turns out.



- 2) If the mixture can not be adjusted by the air screw within 1/2 – 2 turns out range, readjust the slow system ①.

⑤ Fine adjustment of intermediate system

Fine tune the intermediate system by changing the needle type and clip position.

FRONT FORK TUNING

The front fork compression and rebound damping force, and oil level are adjustable for rider's preference, rider's weight and course condition.

NOTE:

- * Break-in new front forks before attempting adjustment.
- * Be sure to adjust both right and left front forks equally.
- * Inspect the following items before attempting adjustment.
 - * Front fork air pressure adjustment. (☞ 2-20)
 - * Front fork damage and oil leakage. (☞ 2-20)
 - * Tire pressure. (☞ 2-21)
 - * Tire and wheel damage. (☞ 2-20)
 - * Spoke nipple tension and rim lock tightness. (☞ 2-21)
 - * Steering movement. (☞ 2-21)

COMPRESSION DAMPING FORCE ADJUSTMENT

- * Turn the adjuster screw ① clockwise until it stops (full hard position).

NOTE:

To set the adjuster, you must gently turn the adjuster screw clockwise until it stops, then back it out the recommended number of turns. Do not force the adjuster screw past the stopped position or you may damage the adjuster.

- * Turn the adjuster screw counterclockwise and the 9th position is the standard position.

DATA Compression damping force adjuster
Standard setting: 9 clicks turns back



REBOUND DAMPING FORCE ADJUSTMENT

- * Turn the adjuster screw clockwise until it stops (full hard position).

NOTE:

To set the adjuster, you must gently turn the adjuster screw clockwise until it stops, then back it out the recommended number of turns. Do not force the adjuster screw past the stopped position or you may damage the adjuster.

- * Turn the adjuster screw ① counterclockwise and the 11th position is the standard position.

DATA Rebound damping force adjuster
Standard setting: 11 clicks turns back



OIL QUANTITY MINOR ADJUSTMENT

ADDING THE FORK OIL

- Remove the air bleed screw (1).
- Add the fork oil with a injector from the air bleed hole.



REDUCING THE FORK OIL

- Remove the front forks. (☞ 16-1)
- Remove the air bleed screw.
- Leaning the front fork, reduce the fork oil from the air bleed hole.



NOTE:

If 5 ml (0.17/0.19 US/Imp oz) of fork oil is added/reduced, the oil level rises/falls approx. 5 mm (0.2 in). Measure the fork oil quantity added/reduced and record it to know the oil quantity after adjustment.

CAUTION

The fork oil quantity must be adjusted equally on both fork legs to provide equal performance.

Operating the motorcycle with the fork oil quantity unevenly adjusted can cause handling instability.

Never mix different types of fork oil. Different oils may cause chemical reaction and deteriorate.

DATA Front fork oil quantity (With standard fork spring used)

Standard: 373 ml (12.61 / 13.13 US/Imp oz)

Oil quantity adjustable range:

331 – 426 ml (11.19/11.65 – 14.40/15.00 US/Imp oz)

MIN 99000-99001-SS5: SUZUKI FORK OIL SS-05

OIL CHANGE (Only for outer tube oil chamber)

- Remove the front forks. (☞ 16-4)
- Thoroughly clean the fork before disassembly.


CAUTION

The fork oil quantity must be adjusted equally on both fork legs to provide equal performance.


Scratches or other damage on the inner tube or on the oil seal lip will cause oil leak.

Avoid scratching or damaging the inner tube or the oil seal. Use a mild detergent or car wash soap and sponge out dirt with plenty of water.

- Clamp the outer tube with a vise. Protect the outer tube with a rag when using a vise. (☞ 16-5)
- Loosen and remove the fork cap bolt (sub-tank) from the outer tube and slowly slide down the outer tube. (☞ 16-5)

 09941-53630: Front fork top cap wrench

- Hold the front fork inverted position for more than 20 minutes to allow the fork oil to fully drain.



- Force out the remaining oil using compressed air completely.



- Slide down the outer tube.
- Pour the specified amount of fork oil into the outer tube.

 99000-99001-SS6: SUZUKI FORK OIL SS-05



	Parts No.	Spring rate	Identification (Slit mark on the spring end)	STD Oil quantity	Oil quantity adjustable range
Soft	51171-36F60	4.0 N/mm (0.40 kgf/mm)	None	370 ml (12.51/13.03 US/Imp oz)	326 – 423 ml (11.09/11.55 – 14.30/14.89 US/Imp oz)
STD	51171-37F00	4.2 N/mm (0.42 kgf/mm)	I	373 ml (12.61/13.13 US/Imp oz)	331 – 426 ml (11.19/11.65 – 14.40/15.00 US/Imp oz)
Hard	51171-37F00	4.4 N/mm (0.44 kgf/mm)	III	368 ml (12.44/12.95 US/Imp oz)	326 – 421 ml (11.02/11.48 – 14.23/14.82 US/Imp oz)

NOTE:

Be sure to adjust the fork oil quantity within the above-mentioned range.

- Raise the outer tube and temporarily tighten the fork cap bolt (sub-tank). (☞ 16-16)

 08941-53630: Front fork cap wrench

- Install the front fork. (☞ 16-18)
- Install the handlebars. (☞ 16-22)

SPRING CHANGE

- Remove the front forks. (☞ 16-4)
- Thoroughly clean the fork before disassembly.

CAUTION

The fork oil quantity must be adjusted equally on both fork legs to provide equal performance.

Scratches or other damage to the inner tube or on the oil seal lip will cause oil leak.

Avoid scratching or damaging the inner tube or the oil seal. Use a mild detergent or car wash soap and sponge out dirt with plenty of water.

- Remove the fork cap bolt and drain fork oil. (☞ 16-5)
- Loosen the center bolt completely. (☞ 16-5)
- Compress the outer tube by hands and install the conrod holder (special tool) between the axle holder bottom (2) and locknut. (☞ 16-6)

 09910-20115: Conrod holder



- Hold the locknut with a wrench and remove the center bolt. (☞ 16-6)
- Remove the push rod. (☞ 16-6)
- Remove the damper rod assembly and fork spring and spring collar. (☞ 16-7)
- Hold the front fork inverted position for more than 20 minutes to allow the fork oil to fully drain. (☞ 4-11)
- Force out the remaining oil using compressed air completely. (☞ 4-11)




- Replace the spring.


	SPRING/No.	SPRING RATE	Identification (Slit mark on the spring end)
Soft	51171-36F80	4.0 N/mm (0.40 kg/mm)	None
STD	51171-37FD0	4.2 N/mm (0.42 kg/mm)	I
Hard	51171-37FC0	4.4 N/mm (0.44 kg/mm)	III



- Install the damper rod assembly. (☞ 16-14)

- Make sure approx. 10 mm (0.39 in.) of inner rod thread is exposed on the end. (☞16-14)



- Insert the push rod into the inner rod.
- Insert the  shaped projection of center bolt into the push rod. (☞16-15)



- Check or adjust the clearance between the locknut and center bolt to provide more than 1 mm (0.04 in.). (☞16-15)
- Tighten the locknut/center bolt to the specified torque.

☑ Locknut/center bolt: 22 N·m (2.2 kgf-m, 16.0 lb-ft)

- Tighten the center bolt to the specified torque.

☑ Center bolt: 70 N·m (7.0 kgf-m, 51.0 lb-ft)



- Pour the specified amount of oil into the outer tube in accordance with the following table.

	SPRING	STD OIL QUANTITY	OIL QUANTITY ADJ. RANGE
Soft	51171-36F60	370 ml (12.51/13.03 US/imp oz)	328 - 423 ml (11.09/11.55 - 14.30/14.89 US/imp oz)
STD	51171-37F00	373 ml (12.61/13.13 US/imp oz)	331 - 426 ml (11.19/11.65 - 14.40/15.00 US/imp oz)
Hard	51171-37F00	368 ml (12.44/12.95 US/imp oz)	328 - 421 ml (11.02/11.48 - 14.23/14.82 US/imp oz)



FRONT FORK TUNING PROCEDURE

Test ride the motorcycle and find out how the front suspension reacts on various types of surfaces. According to the symptom noticed, adjust the front fork to the best setting for rider and race track conditions. To adjust, attempt changing fork oil capacity and compression/rebound damping following the instructions below.

SYMPTOM	SECTION	ADJUSTMENT PROCEDURE
Feels too hard overall	<ul style="list-style-type: none"> • Jump • Large bumps • Series of medium bumps 	<ol style="list-style-type: none"> 1. Adjust both the compression and rebound damping to a softer setting. 2. Decrease fork oil capacity. 3. Replace the spring with an optional softer one.
Feels too soft overall and bottoms	<ul style="list-style-type: none"> • Jump • Large bump • When braking 	<ol style="list-style-type: none"> 1. Adjust the compression damping to a stiffer setting. 2. Increase fork oil capacity. 3. Replace the spring with an optional stiffer one.
Feels too hard near end of travel	<ul style="list-style-type: none"> • Jump 	<ol style="list-style-type: none"> 1. Decrease fork oil capacity.
Feels too soft near end of travel and bottoms harshly	<ul style="list-style-type: none"> • Jump • Large bump 	<ol style="list-style-type: none"> 1. Adjust the compression damping to a stiffer setting. 2. Increase fork oil capacity.
Feels too hard in the beginning of stroke	<ul style="list-style-type: none"> • Jump • Large bump • Series of medium bumps • Series of small bumps 	<ol style="list-style-type: none"> 1. Adjust the compression damping to a softer setting.
Feels too soft and unstable	<ul style="list-style-type: none"> • Series of medium bumps • Series of small bumps 	<ol style="list-style-type: none"> 1. Adjust the rebound damping to a stiffer setting.
Bounces	<ul style="list-style-type: none"> • Jump • Large bump 	<ol style="list-style-type: none"> 1. Adjust the rebound damping to a stiffer setting.
Bounces	<ul style="list-style-type: none"> • Series of small bumps 	<ol style="list-style-type: none"> 1. Adjust the rebound damping to a softer setting.

NOTE:

When adjusting the front fork oil capacity, make sure that the oil level is within the specified range. Also, the capacity should be increased or decreased by 5 ml (0.2 in³) Approx. 5 ml (0.170.18 US/imp oz) at a time. When adjusting the damping setting, attempt turning the adjuster 1 to 2 click stops at a time for each adjustment.

REAR SUSPENSION TUNING

The rear suspension compression and rebound damping force, and spring pre-load are adjustable for rider's preference, rider's weight and course condition.

NOTE:

- * Break-in the rear suspension when riding with a new rear cushion unit. (☞ 1-5)
- * Inspect the following items before attempting adjustment.
 - * Rear shock absorber damage and oil leakage. (☞ 2-20)
 - * Swingarm and links tightness. (☞ 2-20)
 - * Tire pressure. (☞ 2-21)
 - * Tire and wheel damage. (☞ 2-20)
 - * Spoke nipple tension and rim lock tightness. (☞ 2-21)

COMPRESSION DAMPING FORCE ADJUSTMENT

NOTE:

To set the adjuster, you must gently turn the adjuster screw or bolt clockwise until it stops, then back it out the recommended number of turns. Do not force the adjuster screw or bolt past the stopped position, or you may damage the adjuster.

Lo-side

- Turn the adjuster screw ① clockwise until it stops (full hard position).
- Turn the adjuster screw ① counterclockwise and the 6th click is the standard position.

DATA Standard setting: (Lo-side) 6th click

Hi-side

- Turn the adjuster bolt ② clockwise until it stops (full hard position).
- Turn the adjuster bolt ② counterclockwise and 2-1/8 turn out position is the standard position.

DATA Standard setting: (Hi-side) 2-1/8 turns out



REBOUND DAMPING FORCE ADJUSTMENT

NOTE:

To set the adjuster, you must gently turn the adjuster screw clockwise until it stops, then back it out the recommended number of turns. Do not force the adjuster screw past the stopped position, or you may damage the adjuster.

- Turn the adjuster screw ① clockwise until it stops (full hard position).
- Turn the adjuster screw ① counterclockwise and the 11th click is the standard position.

DATA Standard setting: 11th click



SPRING PRE-LOAD ADJUSTMENT

- Place a block under the chassis tube.
- Remove the silencer and rear frame assembly. (C17-3)



- Loosen the locknut (1) with the special tool.

TOOL 09910-60611: Universal clamp wrench

- Turn the adjuster (2) clockwise or counterclockwise to change the spring pre-load.
- Tighten the locknut (1).

DATA Standard spring set length: 6.7 mm (0.264 in)
 (Standard spring set length: 6.7 mm compressed from
 spring free length)
 Spring set length adjustable range: 1 – 15 mm
 (0.039 – 0.591 in)



NOTE:


Turning the adjuster (2) without loosening the locknut (1) can damage the rear cushion unit.

REAR SUSPENSION TUNING PROCEDURE

- Adjust the rear suspension according to the rider's weight and preference by referring to the table below.

Spring	Part No.	Spring rate	Marking paint	Set-length adjustable range
Soft	62211-36F50	48 N/mm (4.6 kgf/mm)	Green	1 – 15 mm (0.039 – 0.591 in.)
	62211-37FA0	48 N/mm (4.8 kgf/mm)	Black	
Standard	62211-37FB0	50 N/mm (5.0 kgf/mm)	Blue	
Hard	62211-36F90	52 N/mm (5.2 kgf/mm)	White	
	62211-36FC0	54 N/mm (5.4 kgf/mm)	Red	

- Measure the distance L1 from the seat bolt to the chain adjuster locknut with the motorcycle on the stand and the rear wheel lifted off the ground.



- Measure the distance L2 from the seat bolt to the chain adjuster locknut with the motorcycle off the stand and riding the motorcycle normally in 1st riding gear.
- Find the sag by subtracting L2 from L1. Standard sag range is 102 mm (4.02 in.).



When the sag measured is:	Adjustment procedure
Less than 102 mm (4.02 in.)	Reduce spring pre-set length by turning the spring adjuster nut.
More than 102 mm (4.02 in.)	Increase spring pre-set length by turning the spring adjuster nut.

After the sag measurement has been set between 97 mm (3.82 in) to 107 mm (4.21 in), test ride the motorcycle and adjust the suspension for the rider and track conditions referring to the guide below.

SYMPTOM	SECTION	ADJUSTMENT PROCEDURE
Feels too hard overall	<ul style="list-style-type: none"> • Jump • Series of bumps 	<ol style="list-style-type: none"> 1. Adjust the low speed compression damping to a softer setting. (See note below) 2. Adjust the rebound damping to a softer setting. (See note below) 3. Replace the spring with an optional softer one. (P. 4-18) 4. Adjust the high speed compression damping to a softer setting. (See note below)
Kicks up	<ul style="list-style-type: none"> • Medium to large bumps 	<ol style="list-style-type: none"> 1. Adjust the low speed compression damping and rebound damping to a harder setting. (See note below) 2. Adjust the high speed compression damping to a harder setting. (See note below)
Bottom feeling or feels too soft and unstable	<ul style="list-style-type: none"> • Jump • Large bump • Series of bumps 	<ol style="list-style-type: none"> 1. Adjust the low speed compression damping to a harder setting. (See note below) 2. Adjust the rebound damping to a harder setting. (See note below) 3. Replace the spring with an optional stiffer one. (P. 4-18)
Feels harsh and hits bumps too harshly	<ul style="list-style-type: none"> • Jump • Large bump • Series of bumps 	<ol style="list-style-type: none"> 1. Adjust the low speed compression damping to a harder setting. (See note below) 2. Adjust the rebound damping to a harder setting. (See note below) 3. If bottom feeling become after adjusting above mentions, adjust the high speed compression damping to a harder setting. (See note below)
Provides poor traction	<ul style="list-style-type: none"> • Accelerating • Series of small bumps 	<ol style="list-style-type: none"> 1. Adjust the rebound damping to a harder setting. (See note below) 2. If traction feeling does not improve after adjusting above mention, adjust the low speed compression damping to a softer setting. (See note below) 3. If bottom feeling become after adjusting above mentions, adjust the high speed compression damping to a harder setting. (See note below)
Tends to sink front than rear	<ul style="list-style-type: none"> • Decelerating or braking 	<ol style="list-style-type: none"> 1. Adjust the high speed compression damping to a softer setting. (See note below) 2. Adjust the rebound damping to a harder setting. (See note below)

NOTE:

When adjusting the damping setting, attempt turning the adjuster 1 to 2 click stops at a time for each adjustment.

SUSPENSION BALANCE

Balancing the front to rear suspension properly is the most critical adjustment for suspension performance. If the front forks are adjusted harder than the rear suspension, such as changing to heavier front fork oil, stiffer compression and rebound setting, air pressure build up in the forks and so on, the front forks will collapse less on bumps. This transfers more of the motorcycle and rider weight rearward, possibly causing the rear suspension to bottom, where as it felt fine before the front fork adjustment was made.

BALANCE TEST

Stand next to the motorcycle on level ground. Place one foot on the foot rest closest to you. Sharply push down. The front and rear suspensions should both collapse equally.

BALANCING TIPS

- Check for air pressure build-up in front forks. Heat and altitude will increase air pressure in the front forks.
- Always stay within sag measurement limits, 97 – 107 mm (3.82 – 4.21 in), when using spring pre-set to stiffen or soften rear suspension. If this is not possible, the next stiffer or softer accessory spring is needed.
- The rear shock compression damping can be used to fine tune suspension balance and is easy to access.

SAMPLE


ENGINE REMOVAL AND INSTALLATION

CONTENTS


EXTERIOR PARTS	5-2
ENGINE REMOVAL AND INSTALLATION	5-3
REMOVAL	5-3
INSTALLATION	5-8

SAMPLE

EXTERIOR PARTS



- Remove the exhaust pipe fitting springs with the special tool.

 09920-20310: Spring hook



- Remove the exhaust muffler mounting bolts.
- Remove the exhaust pipe.




- Remove the exhaust pipe gasket (5).



- Disconnect the radiator hose (6).



- Remove the radiator louvers (7) and bolts (8). (L&R)



- Disconnect the radiator hoses ④ and ⑤.
- Remove the spark plug cap ⑥ and spark plug ⑦.



- Loosen the carburetor clamp screws and remove the carburetor.



- Disconnect the magneto lead wire coupler ⑧.
- Remove the magneto lead wire and breather hose from the clamps.



- Remove the drive chain clip ⑨.
- Remove the drive chain.



- Remove the cover pin ⑤ and brake pedal pivot bolt ⑥.
- Remove the brake pedal.




- Remove the magneto cover ⑦.



- Disconnect the clutch cable.

NOTE:

Loosen the clutch cable adjuster when disconnecting.
( 2-12)



- Extract the clutch cable ⑧.



- Remove the sprocket cover (A).



- Remove the engine mounting bolts and plates.



- Remove the swingarm pivot shaft nut and washer.



- Extract three quarters of the swingarm pivot shaft so as to keep the swingarm in position.

NOTE:

The swingarm will come off when the swingarm pivot shaft is completely removed.

- Remove the engine from the frame.



INSTALLATION

- Reassemble the removed parts in the reverse order of removal.
- Fit the swingarm in its position and hold it with the swingarm pivot shaft.
- Mount the engine on the frame.
- Apply **THREAD LOCK SUPER** to the engine mounting bolt ③.

99000-32030: THREAD LOCK SUPER "1303"

- Tighten the engine mounting nuts.

	Bolt Length
①	45 mm (1.8 in)
②	47.5 mm (1.9 in)
③	80 mm (3.5 in)
④	130 mm (5.1 in)

Tightening torque


	N·m	kgf·m	lb·ft
① (Bolt, Washer, Nut)	43	4.3	31.0
②, ③, ④ (Bolt, Nut)	44	4.4	32.0
⑤ (Shaft, Washer, Nut)	70	7.0	50.5

NOTE:


Replace the self locking nuts with new ones.

- Route the cables, lead wires and hoses correctly. (☞ 18-10, 11, 12, 13, 16, 17)
- Insert the clutch cable positively.

- Reassemble the brake pedal correctly. (☞ 15-15)



- Reassemble the drive chain clip so the slit end faces opposite the direction of rotation.



- Fit the projection of the carburetor to the depression of intake pipe.



- Install the new O-ring (6), connector rubber (7) and gasket (8) to the exhaust pipe.
- Apply a small quantity of engine oil to the O-ring before install the exhaust pipe.



After mounting the engine, inspect the following items.


- Transmission oil level (CF2-9)
- Engine coolant level (CF2-10)
- Throttle cable play (CF2-12)
- Clutch lever play (CF2-12)
- Drive chain slack (CF2-15)

CYLINDER, PISTON AND EXHAUST VALVE**CONTENTS**

CONSTRUCTION	6- 2
CYLINDER, PISTON AND EXHAUST VALVE	6- 2
ENGINE TOP SIDE	6- 3
CYLINDER HEAD REMOVAL	6- 3
CYLINDER REMOVAL	6- 3
PISTON REMOVAL	6- 4
EXHAUST VALVE REMOVAL	6- 5
CYLINDER HEAD INSPECTION	6- 6
CYLINDER INSPECTION	6- 6
PISTON AND PISTON RING INSPECTION	6- 7
EXHAUST VALVE INSPECTION	6- 8
CONROD INSPECTION	6- 8
PISTON RING AND PISTON REASSEMBLY	6- 9
EXHAUST VALVE REASSEMBLY	6- 9
CYLINDER REASSEMBLY	6-10
EXHAUST VALVE GOVERNOR REMOVAL AND DISASSEMBLY	6-12
EXHAUST VALVE GOVERNOR INSPECTION	6-13
EXHAUST VALVE GOVERNOR REASSEMBLY AND INSTALLATION	6-14

CONSTRUCTION

CYLINDER, PISTON AND EXHAUST VALVE



ENGINE TOP SIDE

CYLINDER HEAD REMOVAL

- Remove the seat. (☞5-3)
- Remove the fuel tank. (☞5-3)
- Drain engine coolant. (☞12-3)
- Loosen the clamp and disconnect the radiator hose ①.
- Remove the spark plug cap ② and spark plug ③.
- Remove the nuts, washers ④ and nut ⑤.
- Remove the engine mounting plates ⑥.



- Remove the cylinder head ⑦.

NOTE:

Loosen the cylinder head nuts diagonally to prevent cylinder head distortion.



CYLINDER REMOVAL

- Remove the cylinder head. (☞above).
- Remove the exhaust pipe. (☞6-4)
- Remove the radiator lower.
- Remove the radiator mounting bolts, left and right sides.



- Remove the cylinder head O-rings ① and ②.
- Remove the exhaust valve rod cover ③ and gasket.
- Remove the radiator hose ④, ⑤.



- Remove the exhaust valve bolt (5) from the exhaust valve shaft.

CAUTION

Be careful not to bend the top end of the valve shaft arm spring. Loosen the bolt setting the pin (6) to the lever. If you didn't do that, it cause to bend.




- Remove the four cylinder nuts (7).

NOTE:

Loosen the cylinder nuts diagonally.

- Remove the cylinder (8).



- Remove the gasket (9) and dowel pins (10).

**PISTON REMOVAL**

- Remove the cylinder head and cylinder. (5-3)
- Remove the piston pin circlip (1).

NOTE:

Place cloth on the crankcase to prevent the piston pin circlip from dropping into the crankcase chamber.

- Remove the piston pin (2).
- Remove the piston (3).
- Remove the piston ring (4).
- Remove the conrod small end bearing (5).



EXHAUST VALVE REMOVAL


- Remove the cylinder head and cylinder. (C76-3)
- Remove the breather hoses.
- Remove the exhaust valve cover ①.



- Remove the exhaust valve shaft stop retainer ②.



- Remove the exhaust valve shaft ③, springs ④ and valve shaft arm ⑤.



- Remove the exhaust valve assembly ⑥.



- Remove the side valves, spacers and pins.




CYLINDER HEAD INSPECTION

- Remove carbon deposits from the cylinder head.
- Inspect the cylinder head for cracks around the spark plug hole.
- Inspect for cylinder head distortion.

DATA Cylinder head distortion
Service Limit: 0.05 mm (0.002 in)

TOOL 09900-20803: Thickness gauge

**CYLINDER INSPECTION**

- Remove carbon deposits from the exhaust port.
- Inspect the cylinder for cracks and replace the cylinder if necessary.
- Inspect the cylinder bore for wear and scratches.

NOTE:


Chrome-plated cylinder bore can not be modified such as boring and honing.



- Inspect for cylinder distortion.

DATA Cylinder distortion
Service Limit: 0.05 mm (0.002 in)

TOOL 09900-20803: Thickness gauge




- Measure the cylinder bore for wear with a cylinder gauge 20 mm (0.8 in) from the top surface.

NOTE:

The cylinder bore must be measured perpendicular to the crankshaft axis direction.

DATA Cylinder bore
Standard: 54.000 – 54.015 mm (2.1260 – 2.1266 in)

TOOL 09900-20608: Cylinder gauge set (40 – 80 mm)



PISTON AND PISTON RING INSPECTION

- Remove the piston ring from the piston ring groove.
- Remove carbon deposits from the piston.
- Inspect the piston for wear, scratches and damage.
- Measure the piston outer diameter 19 mm (0.748 in) from the skirt end.

DATA Piston outer diameter

Service Limit: 53.880 mm (2.1213 in)



TOOL 09900-20203: Micrometer (50 – 75 mm)

- Measure the piston pin bore and piston pin diameter.

	Service Limit
Piston pin bore	15.030 mm (0.5917 in)
Piston pin O.D.	14.980 mm (0.5899 in)

TOOL 09900-20205: Micrometer (0 – 25 mm)

09900-20605: Dial gauge




- Remove carbon deposits from piston ring and piston ring groove.
- Fit the piston ring into the ring groove and measure the clearance with a thickness gauge.

DATA Piston ring to groove clearance

Standard: 0.045 – 0.060 mm (0.0018 – 0.0024 in)

TOOL 09900-20803: Thickness gauge



- Fit the piston ring into the cylinder and measure the piston ring end gap with a thickness gauge.

DATA Piston ring end gap

Service Limit: 0.80 mm (0.031 in)

TOOL 09900-20803: Thickness gauge



- Measure the piston ring free end gap.

DATA Piston ring free end gap

Service Limit: 3.4 mm (0.13 in)

TOOL 09900-20101: Vernier calipers



PISTON-TO-CYLINDER CLEARANCE

As a result of the previous measurement, if the piston to cylinder clearance exceeds the following limit, replace both cylinder and piston.

- DATA** Piston to cylinder clearance
Service Limit: 0.12 mm (0.0047 in)

EXHAUST VALVE INSPECTION


- Remove carbon deposits from the exhaust main valve ①, side valves ② and spacers ③.
 - Inspect the exhaust main valve, side valve and spacer for wear and scratches.
 - Inspect the cam groove of the side valve for wear.
- Inspect the return spring ④ for spring tension.

**CONROD INSPECTION**

- Measure the conrod small end bore.

- DATA** Conrod small end bore
Service Limit: 19.040 mm (0.750 in)

- COOL** 09900-20605: Dial gauge



- Fit the piston pin and bearing into the conrod small end and inspect the play.
- Inspect the bearing for smooth movement.



PISTON RING AND PISTON REASSEMBLY

- Apply engine oil to the piston ring and piston ring groove.
- Fit the piston ring into the piston ring groove so the piston ring and comes to the piston ring locating pin. (CF5-11)
- Apply engine oil to the piston pin and bearing.
- Fit the bearing to the conrod small end.



- Face the "O" mark (⊖) on the piston top to the exhaust port side and fit the piston (1).
- Fit the piston pin (2) and piston pin circlip (3). Piston pin circlip end should face upside.

NOTE:

* Replace the piston pin circlip with a new one.

* Place cloth on the crankcase to prevent piston pin circlip from dropping into the crankcase chamber.

**EXHAUST VALVE REASSEMBLY**

- Install the exhaust side valve (1) and spacer (2). (R & L)




- Install the main valve.
- Match the stamped mark "L", "R" of the cylinder to the mark "L", "R" of the side valve and reassemble the side valves.
- Apply engine oil to the exhaust valve (main, side).



- Install the exhaust valve assembly ① checking its direction, right, left, up and down into the cylinder.
- Install the exhaust valve setting its taper part face to down side.
- Tighten the exhaust valve plate bolts.
- Inspect the main and side valve for smooth movement.
- Inspect if the side valve is closed when the main valve is lowered and, at the same time, see if the side valve is open when the main valve is lifted.



- Install the exhaust valve shaft ②, springs ③ and valve shaft arm ④.
- Tighten the exhaust valve shaft bolt.



- Install the exhaust valve shaft stop retainer.
- Install the new gasket and the exhaust valve cover ⑤.
- Install the breather hoses and hose clamp ⑥.



CYLINDER REASSEMBLY



- Install the new gasket ① and the dowel pins ②.
- Apply engine oil to the cylinder bore.
- Hold the piston and piston ring, and insert the piston into the cylinder.



CAUTION


If the piston pin end is not at the proper position, you can not insert the piston into the cylinder properly and the piston ring will be damaged.

Locate the piston ring end to the locating pin and insert the piston into the cylinder.



- Tighten the cylinder nuts to the specified torque according to the specified tightening order as shown.

Cylinder nut: 25 N·m (2.5 kgf-m, 18.0 lb-ft)



- Install the actuator lever to the exhaust valve shaft.
- Tighten the exhaust valve bolt with the pin (included part).

Exhaust valve bolt: 4.5 N·m (0.45 kgf-m, 3.25 lb-ft)

- Install the new gasket and the cover and tighten the bolts.



- Apply grease to the new O-rings and install them to the cylinder.
- Install the cylinder head.

NOTE:

Apply Bond to the stud bolt threads when assembling the removed stud bolts into the cylinder.

99104-31140: SUZUKI BOND "1207B" (USA)

89000-31140: SUZUKI BOND "1207B" (Others)



- Tighten the cylinder head nuts to the specified torque according to the specified tightening order as shown in two steps.

🔧 Cylinder head nut

Initial: 15 N·m (1.5 kgf-m, 11.0 lb-ft)

Final: 25 N·m (2.5 kgf-m, 18.0 lb-ft)



- Reassemble the engine mounting plates.

🔧 Engine mounting nut ①: 44 N·m (4.4 kgf-m, 32.0 lb-ft)

Engine plate nut ②: 43 N·m (4.3 kgf-m, 31.0 lb-ft)

- Reassemble the spark plug and spark plug cap.
- Connect the radiator hose and tighten the clamp (☞ 18-12, 13)
- Reassemble the exhaust pipe (☞ 5-9)
- Pour engine coolant (☞ 2-10)
- Inspect engine coolant leak.



EXHAUST VALVE GOVERNOR REMOVAL AND DISASSEMBLY

- Drain transmission oil. (☞ 2-9)
- Drain engine coolant. (☞ 12-3)
- Remove the exhaust pipe. (☞ 5-4)
- Remove the rear brake pedal (☞ 15-14)
- Remove the clutch cover. (☞ 8-3)
- Remove the exhaust valve bolt. (☞ 6-4)



- Remove the exhaust valve governor ①.



- Remove the exhaust valve actuator ②.



- Remove the pin ② by pushing the retainer ④ down.



- Remove the spring ⑤, retainer ⑥ and bearing ⑦.



- Remove the washers ⑧, spacer ⑨, bearing ⑩ and stator ⑪.



- Remove the balls ⑫.



EXHAUST VALVE GOVERNOR INSPECTION

- Inspect the bearing for wear.
- Replace the bearing if there is anything unusual.



- Inspect the tails and their grooves of governor and actuator for wear or damage.
- If they are worn or damaged, replace them with the new ones.



EXHAUST VALVE GOVERNOR REASSEMBLY AND INSTALLATION

Installation is in the reverse order of removal and disassembly. Pay attention to the following points:

- Apply transmission oil to the exhaust valve governor.
- Install the exhaust valve actuator (1).
- Apply THREAD LOCK to the screws.

 99000-32050: THREAD LOCK "1342"




- Install the exhaust valve governor with the groove (2) engaged with the actuator arm (1).
- Install the actuator lever and exhaust valve rod cover. (CF 6-11)
- Install the brake pedal. (CF 15-15)
- Pour transmission oil. (CF 2-9)
- Pour engine coolant. (CF 2-10)



CLUTCH**CONTENTS**

CONSTRUCTION	7- 2
CLUTCH	7- 2
CLUTCH	7- 3
CLUTCH PLATE REMOVAL	7- 3
CLUTCH PLATE INSPECTION	7- 4
CLUTCH SPRING INSPECTION	7- 4
CLUTCH PUSH ROD INSPECTION	7- 4
CLUTCH PLATE REASSEMBLY	7- 5
PRIMARY DRIVEN GEAR ASS'Y REMOVAL	7- 6
PRIMARY DRIVEN GEAR ASS'Y INSPECTION	7- 7
PRIMARY DRIVEN GEAR ASS'Y REASSEMBLY	7- 7
CLUTCH RELEASE CAMSHAFT REMOVAL	7- 8
CLUTCH RELEASE CAMSHAFT INSPECTION	7- 8
CLUTCH RELEASE CAMSHAFT INSTALLATION	7- 9

**CONSTRUCTION
CLUTCH**

CLUTCH

CLUTCH PLATE REMOVAL

- Drain transmission oil. (☞ 2-9)
- Remove the cotter pin and rear brake pedal. (☞ 15-14)
- Remove the clutch outer cover bolts and clutch outer cover ①.



- Loosen the bolts diagonally and remove them.
- Remove the clutch springs and washers.
- Remove the pressure plate ②.



- Remove the release bearing ③ and clutch push piece ④.



- Remove the clutch push rod ⑤.
- Remove the drive plates ⑥ and driven plates ⑦.




CLUTCH PLATE INSPECTION

- Measure the drive plate thickness.

DATA Drive plate thickness
Service Limit: 2.42 mm (0.096 in)

COB 09900-20101: Vernier calipers


- Inspect the drive plates for wear, distortion and discoloration.



- Measure the driven plate claw width.

DATA Driven plate claw width
Service Limit: 13.05 mm (0.514 in)

COB 09900-20101: Vernier calipers




- Measure the driven plate distortion.

DATA Driven plate distortion
Service Limit: 0.15 mm (0.006 in)

COB 09900-20803: Thickness gauge

- Inspect the driven plates for wear and discoloration.

**CLUTCH SPRING INSPECTION**


- Measure the clutch spring free length.

DATA Clutch spring free length
Service Limit: 37.8 mm (1.49 in)

COB 09900-20101: Vernier calipers

NOTE:

Replace five clutch springs together even if only one spring is beyond the service limit.


**CLUTCH PUSH ROD INSPECTION**

- Inspect the clutch push plate, bearing and push rod for wear and damage.
- Inspect the bearing for smooth movement.



CLUTCH PLATE REASSEMBLY

- Apply transmission oil to the drive plates ① and driven plates ②.
- Fit the clutch push rod ③.
- Install the clutch drive plates and driven plates one by one into the clutch sleeve hub in the prescribed order as show in illustration.



- Apply transmission oil to the release bearing ④.
- Fit the clutch push piece ⑤ and release bearing ④. The roller side of the bearing ④ should face to clutch push piece side.




- Fit the pressure plate ⑥.
- Fit the clutch springs, washers and bolts.
- Tighten the bolts diagonally.

🔧 Clutch spring bolt: 4.5 N·m (0.45 kgf-m, 3.3 lb-ft)



- Replace the O-ring with a new one.
- Fit the clutch outer cover (2).
- Tighten the bolts diagonally.

 Clutch outer cover bolt: 11 N·m (1.1 kgf-m, 8.0 lb-ft)

- Reassemble the rear brake pedal. (☞ 15-15)
- Fill the transmission with specified transmission oil to the correct level. (☞ 2-3)
- Inspect the clutch cable play. (☞ 2-12)




PRIMARY DRIVEN GEAR ASS'Y REMOVAL


- Remove the clutch outer cover.
- Remove the pressure plate and clutch plates. (☞ 7-3)
- Flatten the lock washer (1).
- Hold the clutch sleeve hub with the special tool and loosen the nut (2).

 09920-53740: Clutch sleeve hub holder

- Remove the clutch sleeve hub (3).
- Remove the washer (4) and primary driven gear ass'y (5).

- Remove the snap ring (6), washer and kick idle gear (7).
- Remove the needle bearing (8).
- Remove the spacer (9).

 09800-06107: Snap ring pliers



PRIMARY DRIVEN GEAR ASS'Y INSPECTION

- Inspect the clutch sleeve hub and primary driven gear ass'y for wear and cracks
- Inspect the kick idle gear, needle bearing and spacer for damage and wear.



PRIMARY DRIVEN GEAR ASS'Y REASSEMBLY

- Apply transmission oil to the spacer (1) and needle bearing (2).
- Install the spacer (1) and needle bearing (2).
- Install the kick idle gear (3).
- Install the washer (4), snap ring (5).


 09900-06107: Snap ring pliers



- Install the primary driven gear ass'y (6).
- Install the washer.




- Fit the clutch sleeve hub (7), new lock washer (8) and clutch sleeve hub nut (9).



- Tighten the clutch sleeve hub nut with the special tool to the specified torque.



 08920-53740: Clutch sleeve hub holder

 Clutch sleeve hub nut: 70 N·m (7.0 kgf-m, 51.0 lb-ft)





- Bend the lock washer to secure the nut.





- Reassemble the clutch plates and pressure plate. () 7-5)
- Replace the O-ring with a new one.
- Fit the clutch outer cover and bolts. Tighten the clutch cover bolts diagonally. () 8-5)

 Clutch outer cover bolt: 11 N·m (1.1 kgf-m, 8.0 lb-ft)

- Reassemble the rear brake pedal. () 15-15)
- Refill transmission oil. () 2-9)



CLUTCH RELEASE CAMSHAFT REMOVAL

- Remove the magneto rotor and stator. () 13-5)
- Remove the clutch release camshaft  1.

NOTE:

Loosen the clutch cable adjuster when disconnecting.



CLUTCH RELEASE CAMSHAFT INSPECTION

- Inspect the clutch release camshaft.



- Inspect the oil seal for oil leakage and oil seal lip damage.
- Inspect the bearing for play and smooth movement. (C/10-8)



CLUTCH RELEASE CAMSHAFT INSTALLATION

- Install the clutch release camshaft (1).
- Install the clutch cable.
- Reassemble the magneto rotor and stator. (C/13-8)
- Reassemble the new gasket and magneto cover. (C/13-7)
- Inspect the clutch cable play. (C/2-12)




KICK STARTER

CONTENTS

CONSTRUCTION	8- 2
KICK STARTER	8- 2
KICK STARTER	8- 3
REMOVAL	8- 3
INSPECTION	8- 4
REASSEMBLY	8- 4

SAMPLE

CONSTRUCTION KICK STARTER



KICK STARTER

REMOVAL

- Drain transmission oil. (☞ 2-9)
- Drain engine coolant. (☞ 12-3)
- Remove the cotter pin and rear brake pedal. (☞ 15-14)
- Disconnect the water hose (1).




- Remove the kick starter lever (2).
- Remove the clutch cover bolts and remove the clutch cover (3).
- Remove the clutch. (☞ 7-3)
- Remove the primary driven gear ass'y. (☞ 7-6)




- Remove the kick idle gear snap ring (4).
- Remove the washer and kick idle gear (5).
- Unhook the kick return spring (6).
- Remove the kick starter shaft (7).



 09900-06107: Snap ring pliers

- Remove the following parts from the kick starter shaft:
 - Spring guide (8)
 - Kick return spring (9)
 - Spring (10)
 - Kick starter (11)
- Remove the washer (12) and kick drive gear (13) by removing the snap ring.

 09900-06107: Snap ring pliers




INSPECTION

- Inspect the oil seal ① for oil leakage and oil seal lip damage.
- Inspect the kick drive gear teeth ② for damage.
- Inspect the kick drive gear ratchet part ③ for wear and damage.
- Inspect the kick shaft and drive gear for contact surface ④ wear.
- Inspect the return spring ⑤ for damage.
- Inspect the kick idle gear teeth for damage.
- Inspect the kick idle gear bushing and its shaft contact surface for wear.

**REASSEMBLY**

- Apply grease to the kick shaft.
- Install the kick drive gear ① and washer to the kick shaft.
- Install the snap ring firmly with snap ring pliers.

 09900-06107: Snap ring pliers



- Install the return spring ② into the kick shaft hole.



- Install the spring guide (1) with the groove (6) of the spring guide engaged with the return spring (2).



- Install the kick starter (4) to the kick starter shaft.

NOTE:

Be sure to align the punch marks on the kick starter and kick starter shaft when fitting the kick starter.



- Install the kick starter ass'y to the crankcase. Hook the return spring (2).
- Reassemble the kick idle gear.
- Reassemble the primary driven gear ass'y and clutch. (7-5, 7)



- Reassemble the clutch cover (5) and kick lever (5).

- ☑ Clutch cover bolt: 11 N·m (1.1 kgf-m, 8.0 lb-ft)
- ☑ Kick lever bolt: 23 N·m (2.3 kgf-m, 16.5 lb-ft)



- Install the kick starter lever with punch mark on the lever aligned with the punch mark on the kick shaft.



- Reassemble the rear brake pedal. (C7-15-15)
- Refill transmission oil. (C7-9)
- Refill engine coolant. (C7-10)
- Inspect the clutch lever play.
- Inspect for transmission oil leaks.
- Inspect the kick starter for smooth movement.


SAMPLE

GEARSHIFTING

CONTENTS

CONSTRUCTION	9-2
GEARSHIFT LINKAGE	9-2
GEARSHIFT LINKAGE	9-3
REMOVAL	9-3
INSPECTION	9-4
REASSEMBLY	9-5

SAMPLE

**CONSTRUCTION
GEARSHIFT LINKAGE**

GEARSHIFT LINKAGE

REMOVAL


- Drain transmission oil. (☞ 2-9)
- Drain engine coolant. (☞ 12-3)
- Remove the kick starter lever and clutch cover. (☞ 6-3)
- Remove the clutch assembly. (☞ 7-3)
- Remove the gearshift lever (1).



- Remove the gearshift shaft (2) and washer (3).




- Remove the pawl lifter (4).
- Remove the gearshift cam driven gear (5). Be careful that the pins and springs do not fly off.




- Remove the gearshift pawls (6), pins (7) and springs (8).




- Remove the gearshift cam bolt ④ and stopper plate ①.



- Remove the spring ②.
- Remove the gearshift cam stopper ③.



- Remove the gearshift return spring ⑤ by removing the snap ring.

 09900-06107: Snap ring pliers



INSPECTION

- Inspect the gearshift shaft ① for bends and damage.
- Inspect the return spring ② for damage.




- Inspect the pawls ③, pins ④ and springs ⑤ for damage.




REASSEMBLY

- Reassemble the washer ① and gearshift cam stopper ②. Hook the spring ③ to the projection ④.




- Align the pin groove ⑤ with the pin ⑥ when installing the stopper plate ④.





- Tighten the gearshift cam bolt ⑦.

🔧 Gearshift cam bolt: 24 N·m (2.4 kgf-m, 17.5 lb-ft)



- Fit the springs ⑧, pins ⑨ and pawls ⑩ to the gearshift cam driven gear ⑪. Wider side ⑫ of pawl should be positioned outside.




- With the pawls held in pushed position, install the pawl lifter **(1)**.



- Reassemble the gearshift cam driven gear and pawl lifter.
- Apply **THREAD LOCK SUPER** to the screws.
- Tighten the screws.

99900-32030: THREAD LOCK SUPER "1303"




- Reassemble the gearshift return spring **(1)** to the gearshift shaft **(2)** properly.

09900-06107: Snap ring pliers



- Align the center teeth on the gearshift shaft with the center teeth on the gearshift cam shifter.



- Install the gearshift lever.



- Reassemble the clutch and clutch cover. (☞7-5, 8-5)
- Refill transmission oil. (☞2-9)
- Refill engine coolant. (☞2-10)
- Inspect the gearshift lever for smooth movement.

SAMPLE


TRANSMISSION AND CRANKSHAFT

CONTENTS

CONSTRUCTION	10- 2
TRANSMISSION AND CRANKSHAFT	10- 2
ENGINE BOTTOM SIDE	10- 3
PRIMARY DRIVE GEAR REMOVAL	10- 3
CRANKCASE SEPARATION	10- 4
TRANSMISSION REMOVAL	10- 4
CRANKSHAFT REMOVAL	10- 5
TRANSMISSION INSPECTION	10- 5
CRANKSHAFT INSPECTION	10- 6
OIL SEAL INSPECTION, REMOVAL AND INSTALLATION	10- 7
BEARING INSPECTION	10- 8
BEARING REMOVAL AND INSTALLATION	10- 9
CRANKSHAFT INSTALLATION	10-10
TRANSMISSION REASSEMBLY	10-11
CRANKCASE REASSEMBLY	10-12
PRIMARY DRIVE GEAR REASSEMBLY	10-13

CONSTRUCTION

TRANSMISSION AND CRANKSHAFT



ENGINE BOTTOM SIDE

- Dismount the engine. (☞5-3)

NOTE:

The following parts must be removed before disassembling the engine bottom side (crankcase).

- Remove the engine sprocket (1).
- Remove the gearshift lever. (☞9-3)
- Remove the cylinder head, cylinder and piston. (☞6-3, 4)
- Remove the intake pipe and reed valve. (☞11-7)
- Remove the kick starter lever. (☞8-3)
- Remove the clutch cover and clutch. (☞7-3, 8-3)
- Remove the kick starter idle gear and kick starter shaft. (☞8-3)
- Remove the gearshift linkage. (☞9-3)
- Remove the exhaust valve governor. (☞6-12)



PRIMARY DRIVE GEAR REMOVAL

- Hold the crankshaft immovable with the special tool.

 09930-40113: Rotor holder



- Remove the primary drive gear bolt (1).



- Remove the washer (2) and primary drive gear (3).
- Remove the magneto rotor, stator and key. (☞13-5)
- Remove the clutch release camshaft. (☞7-8)




CRANKCASE SEPARATION

- Remove the engine sprocket spacer ① and two O-rings ②.



- Remove the crankcase bolts.



- Separate the crankcase with the special tool.


 09920-13120: Crankcase separating tool

NOTE.

- * Set the crankcase separating tool to the clutch side of the crankcase.
- * Separate the crankcase gradually while hitting the crankcase boss and countershaft softly with a plastic hammer.

**TRANSMISSION REMOVAL**

- Remove the dowel pin ① and gasket ②.



- Remove the gearshift fork shafts ③.
- Remove the gearshift cam ④.
- Remove the gearshift forks ⑤.



- Remove the driveshaft ass'y (2) and countershaft ass'y (3).



CRANKSHAFT REMOVAL

- Remove the crankshaft with the special tool.


max 09920-13120: Crankcase separating tool

CAUTION
Be careful not to damage the thread part of the crankshaft.



TRANSMISSION INSPECTION

- Inspect the gear teeth, dogs, and gearshift grooves for abnormal wear and damage.
- Inspect the bushings and splines for abnormal wear and discoloration.



- Inspect the gearshift cam groove for abnormal wear and damage.




- Inspect the gearshift forks and shafts for wear and damage.



- Measure the gearshift fork thickness with a vernier calipers.

DATA Gearshift fork thickness
Standard: 4.80 – 4.90 mm (0.189 – 0.193 in)

TOOL 09900-20101: Vernier calipers



- Measure the gearshift fork groove width with a vernier calipers.

DATA Gearshift fork groove width
Standard: 4.95 – 5.05 mm (0.195 – 0.199 in)


TOOL 09900-20101: Vernier calipers



- Measure the gearshift fork to groove clearance with a thickness gauge.

DATA Gearshift fork to groove clearance
Service Limit: 0.45 mm (0.018 in)

TOOL 09900-20803: Thickness gauge




CRANKSHAFT INSPECTION

- Measure the conrod deflection with the special tools.

DATA Conrod deflection
Service Limit: 3.0 mm (0.12 in)

TOOL 09900-20606: Dial gauge (1/100 mm)
09900-20701: Magnetic stand
09900-21304: V-block



- Measure the conrod big end side clearance with the thickness gauge.

DATA Conrod big end side clearance
Service Limit: 1.0 mm (0.04 in)

TOOL 09900-20803: Thickness gauge



- Measure the crankshaft runout with V-blocks and dial gauge.


DATA Crankshaft runout

Service Limit: 0.05 mm (0.002 in)

tool 09900-20606: Dial gauge (1/100 mm)

09900-20701: Magnetic stand

09900-21304: V-block




- Measure the crankshaft web to web width with a vernier callipers.

DATA Width between webs

Standard: 53.9 – 54.1 mm (2.122 – 2.130 in)

tool 09900-20101: Vernier callipers



OIL SEAL INSPECTION, REMOVAL AND INSTALLATION

- Inspect each oil seal lip for wear and damage.



- Remove the oil seal with the special tool.

tool 09913-50121: Oil seal remover



- Fit each new oil seal with the special tools.
- Apply grease to each oil seal lip.


08913-70210: Bearing installer set

- Oil seal ①: ϕ 30 Attachment
- Oil seal ②: ϕ 40 Attachment
- Oil seal ③: ϕ 35 Attachment
- Oil seal ④: ϕ 22 Attachment
- Oil seal ⑤: ϕ 47 Attachment




NOTE:

Be sure to check the direction of the crankshaft bearing oil seals before fitting them.



BEARING INSPECTION

- Inspect the bearings for play, discoloration, wear and seizure.
- Move the inner race by finger and inspect for smooth movement.



BEARING REMOVAL AND INSTALLATION**REMOVAL**

- Remove the bearing retainers
- Remove the bearings with the special tools.
Bearing ①, ②, ③, ④: ϕ 35 Attachment
Bearing ⑤, ⑥: ϕ 30 Attachment

 09913-70210: Bearing remover/installer set



- Remove the bearings ⑦, ⑧


 09921-20240: Bearing remover set



- Remove the bearings ③, ④

 09917-50410: Bearing remover

- Remove the bearing ⑥

 09921-20200: Bearing remover
09930-30104: Sliding shaft



INSTALLATION

- Press the bearings with the special tools

Bearing ①, ⑤: ϕ 55 Attachment

Bearing ②: ϕ 47 Attachment

Bearing ③, ④: ϕ 42 Attachment

Bearing ⑥: ϕ 52 Attachment

Bearing ⑦: ϕ 40 Attachment

Bearing ⑧: ϕ 35 Attachment

Bearing ⑨, ⑩: ϕ 22 Attachment



Bearing ⑪: ϕ 15 Attachment

 08813-70210: Bearing remover/installer set

- Apply THREAD LOCK SUPER to the shift cam bearing retainer screws.

 99000-32030: THREAD LOCK SUPER "1303"

- Tighten the bearing retainer screws.

**CRANKSHAFT INSTALLATION**


- Fit the crankshaft into the left crankcase half with the special tool.

 08910-32612: Crankshaft installer


09910-32620: Crankshaft installer attachment



TRANSMISSION REASSEMBLY

**NOTE:**

Seat the circlip in the groove and locate its end as shown in the illustration.



- Apply transmission oil to the following parts: driveshaft, countershaft, transmission gears, bearings
- Reassemble the driveshaft ① and countershaft ② with gears installed.

NOTE:

Install the washers ③, ④ located in both ends of the driveshaft positively.



- Apply transmission oil to the following parts: bearings, gearshift forks, gearshift shafts gearshift cam.
- Reassemble the gearshift forks ①, ②, ③.



- Install the gearshift cam ④ and gearshift shafts ②, ③.

NOTE:

Turn the gearshift cam to the neutral position and confirm that the driveshaft and countershaft turn without resistance.

**CRANKCASE REASSEMBLY**

- Install the new gasket and dowel pins.
- Install the right crankcase half on the left crankcase half.
- Tighten the crankcase bolts.

ⓘ Crankcase bolt: 10 N·m (1.0 kgf-m, 7.3 lb-ft)

NOTE:

If it is hard to tighten the bolts, separate the crankcase and confirm that the transmission parts are assembled correctly. Install the clamp to the bolt ④.



- Inspect the crankshaft for smooth movement.
- Apply grease to Oil seal and O-rings ①. Fit the O-rings ① and spacer ② to the driveshaft.



PRIMARY DRIVE GEAR REASSEMBLY

- Reassemble the clutch release camshaft. (☞7-9)
- Reassemble the stator and magneto rotor. (☞13-8)
- Install the washer and primary drive gear.


NOTE:

The washer is directional. Assemble the washer ① as shown in the illustration.

- Hold the magneto rotor with the special tool and tighten the primary drive gear bolt to the specified torque.

max 09930-40113: Rotor holder

- Primary drive gear bolt: 70 N·m (7.0 kgf-m, 50.5 lb-ft)



- Reassemble the gearshift linkage. (☞9-5)
- Reassemble the kick idle gear and kick starter shaft. (☞8-4)
- Reassemble the exhaust valve governor. (☞6-14)
- Reassemble the clutch and clutch cover. (☞7-5, 7, 8-5)
- Reassemble the piston, cylinder and cylinder head. (☞6-9, 10, 12)
- Reassemble the intake pipe and reed valve. (☞11-7)
- Reassemble the engine sprocket.
- Reassemble the engine. (☞5-8)
- Reassemble the kick starter lever. (☞8-5)
- Reassemble the gearshift lever. (☞9-6)
- Pour transmission oil and coolant. (☞2-9, 10)


FUEL SYSTEM

CONTENTS

CARBURETOR	11- 2
CONSTRUCTION	11- 2
REMOVAL AND DISASSEMBLY	11- 3
CLEANING	11- 5
INSPECTION	11- 5
REASSEMBLY	11- 6
REED VALVE	11- 7
REMOVAL	11- 7
INSPECTION	11- 7
REASSEMBLY	11- 7

SAMPLE

CARBURETOR CONSTRUCTION



REMOVAL AND DISASSEMBLY


- Disconnect the fuel hose (1) (2-5-3)
- Loosen the carburetor clamp screws and remove the carburetor.



- Remove the carburetor top cap (3).




- Compressing the spring (2) with the collar (3), disconnect the throttle cable from the throttle valve (4).



- Remove the cable holder (6) and jet needle (7).



- Remove the fuel hose (1), air vent hoses (8), overflow hoses (9).



- Remove the float chamber.



- Remove the holder ⑫.
- Remove the floats ⑪ and needle valve ⑬.



- Remove the needle valve seat ⑭.
- Remove the main jet ⑮ and needle jet holder ⑯.
- Remove the pilot jet ⑰.



- Remove the needle jet ⑱.



- Remove the starter knob ⑲.
- Remove the locknut and throttle stop screw ⑳.
- Remove the air screw ㉑ and spring.
- Remove the filter ㉒.



CLEANING

▲ WARNING

Some carburetor cleaning chemicals, especially dip-type soaking solutions, are very corrosive and must be handled carefully. Always follow the chemical manufacturer's instructions on proper use, handling and storage.

- Clean all jets with a spray-type carburetor cleaner and dry them using compressed air.
- Clean all circuits of the carburetor thoroughly, not just the perceived problem area. Clean the circuits in the carburetor body with a spray-type cleaner and allow each circuit to soak if necessary to loosen dirt and varnish. Blow the body dry using compressed air.


CAUTION

Do not use a wire to clean the jets or passageways. A wire can damage the jets and passageways. If the components cannot be cleaned with a spray cleaner, it may be necessary to use a dip-type cleaning solution and allow them to soak. Always follow the chemical manufacturer's instructions for proper use and cleaning on the carburetor components.

- After cleaning, reassemble the carburetor.

CAUTION

Replace the removed O-rings with new ones.



INSPECTION


Check the following parts for damage or clogging. If any damage is found, replace the parts with a new one.

- Throttle valve
- Jet needle
- Hoses
- Floats
- Main jet
- Needle jet holder
- Pilot jet
- Needle jet



NEEDLE VALVE INSPECTION

If foreign matter is caught between the valve seat and the needle valve, the fuel will continue flowing and overflow. If the valve seat and needle valve are worn beyond the permissible limits, similar trouble will occur. Conversely, if the needle valve sticks, the fuel will not flow into the float chamber. Clean the float chamber and float parts with gasoline. If the needle valve is worn, as shown in the illustration, replace it along with a new valve seat. Clean the fuel passage of the mixing chamber using compressed air.

**FLOAT HEIGHT ADJUSTMENT**

• Measure the float height with the vernier calipers. To measure the float height, lift the carburetor until the float tip just contacts the needle valve.

DATA Standard float height ϕ : 8.7 ± 1.0 mm (0.34 ± 0.04 in)

TOOL 09900-20101: Vernier calipers

**REASSEMBLY**

Reverse the sequence of removal.

NOTE:

Fit the projection of throttle valve collar in the groove of cable holder.



• Fit the projection on the carburetor body to the depression of the intake pipe.



REED VALVE

REMOVAL

- Remove the carburetor. (☞ 11-3)
- Remove the intake pipe and reed valve.



INSPECTION

- Inspect the reeds for damage.
- Inspect the reed valve stoppers for damage.
- Inspect the valve seal rubber for damage.

NOTE:


Be careful not to damage the removed reed valve assembly.



REASSEMBLY

Reverse the sequence of removal.

- Tighten the intake pipe bolt to the specified torque.

 Intake pipe bolt: 4.5 N·m (0.45 kgf·m, 3.5 lb-ft)




COOLING SYSTEM

CONTENTS

CONSTRUCTION	12- 2
COOLING SYSTEM	12- 2
ENGINE COOLANT	12- 3
ENGINE COOLANT REPLACEMENT	12- 3
RADIATOR	12- 3
RADIATOR CAP INSPECTION	12- 3
RADIATOR REMOVAL	12- 4
COOLING SYSTEM INSPECTION	12- 4
RADIATOR INSTALLATION	12- 5
WATER PUMP	12- 5
WATER PUMP REMOVAL AND INSPECTION	12- 5
WATER PUMP REASSEMBLY	12- 6

SAMPLE

**CONSTRUCTION
COOLING SYSTEM**

ENGINE COOLANT

ENGINE COOLANT REPLACEMENT

▲ WARNING

You can be injured by scalding fluid or steam if you open the radiator cap when the engine is hot.

Do not open the radiator cap when the engine is hot. Wait until engine cools.

- Place the motorcycle on a block.
 - Remove the radiator cap.
 - Remove the drain plug (1) and drain engine coolant.
 - Tighten the drain plug (1).
 - Pour specified coolant through the radiator inlet hole up to the bottom of filler hole. (2-10)
- NOTE** Engine coolant capacity: 1 100 ml (1.2/1.0 US/Imp qt)
- Tighten the radiator cap firmly.
 - Run the engine a few minutes and inspect the coolant level.



RADIATOR


RADIATOR CAP INSPECTION

- Inspect the radiator cap for function with a radiator cap pressure gauge.

NOTE Radiator cap valve release pressure:
95 – 125 kPa (0.95 – 1.25 kg/cm², 13.5 – 17.8 psi)

NOTE:

Apply water to radiator cap seal before fitting the radiator cap to the pressure gauge.



RADIATOR REMOVAL

- Remove the seat and fuel tank. (C75-3)
- Drain engine coolant.
- Disconnect the outlet hose (1).
- Remove the radiator lowers (2). (R & L)
- Remove the radiator mounting bolts (3). (R & L)



- Disconnect the radiator lower joint hose (4).



- Disconnect the radiator upper joint hose (5).



- Disconnect the inlet hose (6).

**COOLING SYSTEM INSPECTION**

Inspect the following items.

- Radiator coolant leakage
- Radiator hose cracks and deterioration
- Radiator mounting condition
- Radiator breather hose condition
- Radiator fan condition

RADIATOR INSTALLATION

Reverse the sequence of removal.

- Install the radiator hoses. (☞ 18-12, 13)
- Remount the radiator.

WATER PUMP

WATER PUMP REMOVAL AND INSPECTION

- Drain engine coolant and transmission oil. (☞ 2-9, 12-3)
- Disconnect the radiator hose ①.
- Remove the water pump cover ②.
- Remove the clutch cover. (☞ 8-3)



- With the water pump shaft ③ held immovable, remove the water pump impeller ④.
- Inspect the impeller for damage.



CAUTION
The water pump impeller bolt has left-hand threads.

The water pump impeller bolt has left-hand threads.



- Inspect the impeller and water pump gear for damage.



- Inspect the bearing for smooth inner race movement.



- Remove the bearing with the special tool.

 99921-20240: Bearing remover set



- Inspect the oil seal for damage.



- Remove the oil seal with the suitable size socket wrench.



WATER PUMP REASSEMBLY

- Apply THREAD LOCK to the outer surface of the oil seal. (USA)
- Apply THREAD LOCK SUPER to the outer surface of the oil seal. (Others)


 99000-32050: THREAD LOCK "1342" (USA)

 99000-32110: THREAD LOCK SUPER "1322" (Others)

- Press the oil seal with the suitable size socket wrench.
- Apply grease to the oil seal lip.




- Press the bearing with the special tool.

 09913-70210: Bearing installer set

NOTE:

When installing the bearing the stamped mark on the bearing must face outside.




- Hold the water pump shaft with a wrench and tighten the impeller bolt to the specified torque.

 Impeller bolt: 10 N·m (1.0 kgf-m, 7.3 lb-ft)



SAMPLE

- Replace the water pump case gasket with a new one.
- Reassemble the clutch cover and water pump cover.
(☐ 8-5)
- Connect the radiator hose.
- Pour engine coolant and transmission oil. (☐ 2-9, 10)




ELECTRICAL SYSTEM

CONTENTS


CONSTRUCTION	13- 2
ELECTRICAL SYSTEM	13- 2
ELECTRICAL CIRCUIT	13- 2
IGNITION SYSTEM	13- 3
IGNITION SYSTEM PEAK VOLTAGE INSPECTION	13- 3
IGNITION COIL INSPECTION	13- 4
CDI UNIT INSPECTION	13- 4
STATOR COIL INSPECTION	13- 5
MAGNETO ROTOR AND STATOR REMOVAL	13- 5
MAGNETO ROTOR AND STATOR REASSEMBLY	13- 6

SAMPLE

CONSTRUCTION ELECTRICAL SYSTEM



ELECTRICAL CIRCUIT



Color code:

B/R: Black with Red tracer

B/W: Black with White tracer

B/Y: Black with Yellow

G: Green

R: Red

R/W: Red with White tracer

W/B: White with Blue tracer

IGNITION SYSTEM

IGNITION SYSTEM PEAK VOLTAGE INSPECTION

- Remove the seat and fuel tank. (☞5-3)
- Remove the spark plug.
- Disconnect the magneto lead wire coupler ①.

Measure the ignition system peak voltage in the following procedure:

- Connect the multi circuit tester with peak volt adaptor as follows. (See table below.)
- Measure the highest peak voltage by depressing the kick starter lever several times forcefully.

DATA

Red/White – Black/Red	30 V and more
Green – Red	3 V and more

☞ 09900-25008: Multi circuit tester set
Tester knob indication: Voltage (V)



- Connect the magneto lead wire coupler and disconnect the ignition coil lead wire coupler ②.
- Connect the multi circuit tester with peak volt adaptor between Black/White lead wire and White/Blue lead wire.
- Measure the highest peak voltage by depressing the kick starter lever several times forcefully.

DATA

Black/White – White/Blue	210 V and more
--------------------------	----------------

NOTE:

Be sure the Red probe pin is connected to the Black/White lead wire and Black probe pin to the White/Blue lead wire.



IGNITION COIL INSPECTION

- Remove the seat and fuel tank. (C/A 5-3)
 - Disconnect the ignition coil lead wire coupler ①.
- Measure the ignition coil electrical resistance.

DATA

Primary	White/Blue – Black/ White	0.15 – 0.45 Ω
Secondary	Plug cap – White/ Blue	12 – 21 k Ω

- TOOL** 09900-23006: Multi circuit tester set
Tester knob indication: Resistance (Ω)


**CDI UNIT INSPECTION**

- Remove the front number plate.



- Remove the CDI unit ② from the frame.
- Measure voltage between the lead wires with the multi circuit tester.

- TOOL** 09900-23006: Multi circuit tester set
Tester knob indication: Diode (←→)

**CDI unit coupler terminal number**

DATA

Unit: V

		Positive (+) probe pin (Diode terminal)											
		(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(9)	(10)	(11)	(12)
Negative (-) probe pin (COM terminal)	DCM (1)	—	—	—	—	0.295 -0.595	1.017 -1.527	0.690 -1.190	1.177 -1.527	0.628 -1.230	0.440 -1.045	0.0 0.3	—
	(2)	—	—	—	—	—	—	—	—	—	—	—	—
	(3)	—	—	—	—	—	—	—	—	—	—	—	—
	(4)	0.407 -1.007	—	—	—	0.052 -1.260	1.128 -1.527	1.029 -1.527	1.193 -1.527	0.964 -1.527	0.775 -1.375	0.407 -1.007	—
	(5)	0.176 -0.774	—	—	—	—	1.019 -1.527	0.817 -1.417	1.178 -1.527	0.760 -1.386	0.609 -1.223	0.176 -0.774	—
	(6)	1.006 -1.527	—	—	—	1.028 -1.527	—	1.189 -1.527	1.158 -1.527	1.119 -1.527	1.040 -1.527	1.006 -1.527	—
	(7)	—	—	—	—	—	—	—	—	—	—	—	—
	(8)	0.133 -0.733	—	—	—	0.498 -1.098	1.001 -1.527	0.952 -1.525	—	0.751 -1.351	0.693 -1.293	0.133 -0.733	—
	(9)	0.180 -0.780	—	—	—	0.577 -1.177	1.101 -1.527	0.954 -1.527	1.168 -1.527	—	0.691 -1.291	0.180 -0.780	—
	(10)	0.448 -1.048	—	—	—	0.533 -1.260	1.052 -1.527	0.890 -1.490	1.177 -1.527	0.838 -1.438	—	0.448 -1.048	—
	(11)	0.5 0.3	—	—	—	0.234 -0.594	1.016 -1.527	0.692 -1.192	1.176 -1.527	0.638 -1.230	0.445 -1.045	—	—
	(12)	—	—	—	—	—	—	—	—	—	—	—	—

NOTE:


— is open circuit voltage (tester's battery voltage).

STATOR COIL INSPECTION

- + Remove the seal and fuel tank. (☐ 5-3)
 - + Disconnect the magneto lead wire coupler (1).
- Measure the stator coils electrical resistance.


DATA

Red/White – Black/Red	18 – 30 Ω
Green – Red	75 – 125 Ω


 09900-25008: Multi circuit tester set
Tester knob indication: Resistance (Ω)

MAGNETO ROTOR AND STATOR REMOVAL

- + Remove the bolts and magneto cover (1).
- + Disconnect the lead wire coupler. (☐ 13-3)



- Remove the nut with a special tool.

 09930-40113: Rotor holder



- Remove the magneto rotor with the special tool.

 09930-30113: Flywheel rotor remover



- Remove the bolts and remove the stator.



MAGNETO ROTOR AND STATOR REASSEMBLY


- Fit the key (1) into the crankshaft.




- Align the line on the stator with the line on the crankcase to set the ignition timing correctly.




- Install the magneto rotor.
- Tighten the nut to the specified torque with the special tool


 09930-40113: Rotor holder

 Magneto rotor nut: 35 N·m (3.5 kgf-m, 25.5 lb-ft)



- Replace the gasket with a new one.
- Reassemble the magneto cover (2).

 Magneto cover bolt: 11 N·m (1.1 kgf-m, 8.0 lb-ft)




SAMPLE

FRONT AND REAR WHEELS

CONTENTS

CONSTRUCTION	14- 2
FRONT WHEEL	14- 3
REMOVAL	14- 3
INSPECTION	14- 3
BEARING REPLACEMENT	14- 4
DISC PLATE REPLACEMENT	14- 5
INSTALLATION	14- 5
REAR WHEEL	14- 6
REMOVAL	14- 6
INSPECTION	14- 6
BEARING REPLACEMENT	14- 7
DISC PLATE REPLACEMENT	14- 7
REAR SPROCKET REPLACEMENT	14- 8
INSTALLATION	14- 8

CONSTRUCTION



FRONT WHEEL

REMOVAL

- Place the motorcycle on a block to lift front wheel off the ground.
- Remove the axle nut ①.
- Loosen the left axle holder bolts ②.
- Loosen the right axle holder bolts ③.
- Remove the front axle shaft ④.
- Remove the front wheel.



INSPECTION

SPACER AND DUST SEAL

- Inspect the right and left wheel spacers and dust seals for wear and cracks.
- If any damage is found, replace the spacer together with the dust seal.

NOTE:

Apply grease to the spacer and dust seal before reassembling.




AXLE SHAFT

- Support the axle shaft with the V-blocks and measure the axle shaft runout.


DATA Axleshaft runout
Service Limit: 0.25 mm (0.010 in)


TOOLS 09900-20607: Dial gauge (1/100 mm)
09900-20701: Magnetic stand
09900-21304: V-block set (100 mm)




WHEEL RIM

- Measure the wheel rim runout with the dial gauge

 Service Limit: 2.0 mm (0.08 in) ... axial and radial

 09900-20607: Dial gauge (1/100 mm)
09900-20701: Magnetic stand

**WHEEL BEARING**

- Turn the inner race by finger and inspect it for smooth movement.
- Inspect the clearance between the outer race and wheel hub.
- Inspect for bearing damage.


**BEARING REPLACEMENT**

- Remove the dust seals with the special tool.

 09913-50121: Oil seal remover



- Remove the bearings with the special tool

 09921-20240: Bearing remover set

- Removes the spacer.



- Apply grease to the bearings.
- Reassemble the bearings and spacer with the special tool.
- Fit the dust seals and apply grease to their lips.


 09941-34513: Bearing installer set

 99000-25030: SUZUKI SUPER GREASE "A" (USA)

99000-25010: SUZUKI SUPER GREASE "A" (Others)

NOTE:

- * Install the left side (disc side) bearing first and then the right side bearing.
- * After installing the bearings, inspect the bearings for smooth movement.
- * When installing the dust seal, place the manufacturer's code indicated side of the dust seal outside.



DISC PLATE REPLACEMENT

- Remove the disc plate.
- Apply THREAD LOCK to the bolts. (USA)
- Apply THREAD LOCK SUPER to the bolts. (Others)

 99000-32050: THREAD LOCK "1342" (USA)

 99000-32110: THREAD LOCK SUPER "1322" (Others)

- Tighten the bolts to the specified torque.

 Disc plate bolt: 10 N·m (1.0 kgf-m, 7.0 lb-ft)




INSTALLATION

- Hold the axle shaft with the special tool and tighten the axle nut temporarily.

 09940-34581: Attachment (F)



- Remove the block from under the chassis tube and move the front forks up and down several times.
- Tighten the axle nut to the specified torque.

 Axle nut: 35 N·m (3.5 kgf-m, 25.5 lb-ft)

- Tighten the left and right axle holder bolts to the specified torque.

 Axle holder bolt: 16 N·m (1.6 kgf-m, 13.0 lb-ft)



REAR WHEEL

REMOVAL

- Place the motorcycle on a block to lift the rear wheel off the ground.
- Remove axle nut ① and washer ②.



- Remove the rear axle shaft ③ and chain adjuster washers ④.
- Disengage the drive chain.
- Remove the rear wheel.



INSPECTION

WHEEL SPACER

- Inspect the rear wheel spacers and dust seals for wear and cracks.
- If any damage is found, replace the spacer together with the dust seal.

NOTE:

Apply grease on the spacer and dust seal before reassembling.



AXLE SHAFT (☞14-3)

- DATA** Axle shaft runout
Service Limit: 0.25 mm (0.010 in)


WHEEL RIM (☞14-4)

- DATA** Service Limit: 2.0 mm (0.08 in) ... axial and radial

WHEEL BEARING (☞14-4)

BEARING REPLACEMENT

- Remove the dust seals with the special tool.

 09913-50121: Oil seal remover



- Remove the bearings with the special tool.


 09921-20240: Bearing remover set

- Remove the spacer.



- Apply grease to the bearings.
- Reassemble the bearings and spacer with the special tool.
- Fit the dust seals and apply grease to their lips.


 09941-34513: Bearing installer set

 99000-25030: SUZUKI SUPER GREASE "A" (USA)

99000-25010: SUZUKI SUPER GREASE "A" (Others)

NOTE:

- Install the right side (disc side) bearing first and then the right side bearing.
- After installing the bearings, inspect the bearings for smooth movement.
- When installing the dust seal, place the manufacturer's code indicated side of the dust seal outside.



DISC PLATE REPLACEMENT

- Remove the disc plate.
- Apply THREAD LOCK to the bolts. (USA)
- Apply THREAD LOCK SUPER to the bolts. (Others)

 99000-32050: THREAD LOCK "1342" (USA)

 99000-32110: THREAD LOCK SUPER "1322" (Others)

- Tighten the bolts to the specified torque.

 Disc plate bolt: 10 N·m (1.0 kgf-m, 7.0 lb-ft)



REAR SPROCKET REPLACEMENT


- Remove the rear sprocket.

NOTE:

Install the rear sprocket as the letter on the sprocket surface faces outside.




- Tighten the bolts/nuts to the specified torque.

 Rear sprocket bolt/nut: 30 N·m (3.0 kgf-m, 21.5 lb-ft)




INSTALLATION

- Install the rear wheel, chain adjuster washers and axle shaft.
- Adjust the drive chain slack. (2-18)



- Tighten the axle nut to the specified torque.

 Rear axle nut: 100 N·m (10.0 kgf-m, 72.5 lb-ft)




FRONT AND REAR BRAKES

CONTENTS

CONSTRUCTION	15- 2
BRAKE FLUID AIR BLEEDING	15- 3
BRAKE FLUID REPLACEMENT	15- 4
BRAKE PADS REPLACEMENT	15- 5
FRONT BRAKE PADS	15- 5
REAR BRAKE PADS	15- 5
BRAKE DISC INSPECTION	15- 6
CALIPER	15- 6
FRONT CALIPER REMOVAL AND DISASSEMBLY	15- 7
REAR CALIPER REMOVAL AND DISASSEMBLY	15- 8
CALIPER INSPECTION	15- 8
CALIPER CLEANING	15- 9
FRONT CALIPER REASSEMBLY	15- 9
REAR CALIPER REASSEMBLY	15-10
MASTER CYLINDER	15-11
FRONT MASTER CYLINDER REMOVAL AND DISASSEMBLY	15-11
REAR MASTER CYLINDER REMOVAL AND DISASSEMBLY	15-12
MASTER CYLINDER INSPECTION	15-13
MASTER CYLINDER CLEANING	15-13
FRONT MASTER CYLINDER REASSEMBLY	15-13
REAR MASTER CYLINDER REASSEMBLY	15-14
BRAKE PEDAL	15-14
REMOVAL	15-14
REASSEMBLY	15-15

CONSTRUCTION



BRAKE FLUID AIR BLEEDING

▲ WARNING

Brake fluid can be hazardous to humans and pets. Brake fluid is harmful or fatal if swallowed, and harmful if it comes in contact with your skin or eyes.

Keep brake fluid away from children. Call your doctor immediately if brake fluid is swallowed and induce vomiting. Flush eyes or skin with water if brake fluid gets in eyes or comes in contact with skin.

▲ WARNING

The use of any fluid except DOT4 brake fluid from a sealed container can damage the brake system and lead to an accident.

Use only DOT4 brake fluid from sealed container. Never use or mix different types of brake fluid.

CAUTION

Spilled brake fluid can damage painted surfaces and plastic parts.

Be careful not to spill any brake fluid when servicing brake fluid. Wipe spilled fluid up immediately.

- Remove the reservoir cap.
- Connect a transparent tube to the bleeder valve and set the other end into a receptacle.
- Pour brake fluid up to the UPPER line.
- Pump the brake lever/pedal until air bubbles stop coming out from the reservoir.
- Hold the brake lever/pedal in the squeezed position.
- Open the bleeder valve and tighten the bleeder valve.
- Release the brake lever/pedal.
- Repeat this sequence until air bubbles stop coming out from the bleeder valve.

**NOTE:**

Do not release the brake lever/pedal while the bleeder valve is opened.

- Replenish brake fluid to the UPPER line when the brake fluid level drops below LOWER line.






- Tighten the air bleeder valve.

 **Air bleeder valve: 5.0 N·m (0.6 kgf-m, 4.4 lb-ft)**

- Pour brake fluid up to the UPPER line.
- Reassemble the reservoir cap.




BRAKE FLUID REPLACEMENT

- Remove the reservoir cap. ( above)
- Connect a transparent tube to the bleeder valve and set the other end into a receptacle. ( above)
- Loosen the bleeder valve and pump the brake lever/pedal until brake fluid stops coming out from the bleeder valve.
- Pour brake fluid into the reservoir.
- Bleed air from the brake system. ( above)
- Reassemble the reservoir cap.

BRAKE PADS REPLACEMENT

FRONT BRAKE PADS

- Remove the cap (1) and pad mounting pin (2).



- Remove the brake pads.

NOTE:

Replace the two brake pads as a set.

- Fit the new brake pads into the caliper and tighten the pad mounting pin to the specified torque.

T Brake pad mounting pin: 17.5 N·m (1.75 kgf·m, 13.2 lb-ft)

NOTE:

Pump the brake lever several times to seat the brake pads after reassembling.



REAR BRAKE PADS

- Remove the cap (1) and pad mounting pin (2).



- Remove the brake pads.

NOTE:

Replace the two pads as a set.

- Fit the brake pads into the caliper.
- Tighten the brake pad mounting pin to the specified torque.

T Brake pad mounting pin: 17.5 N·m (1.75 kgf·m, 13.2 lb-ft)

NOTE:

Pump the brake pedal several times to seat the brake pads after reassembling.




BRAKE DISC INSPECTION

- Measure the front and rear brake disc thickness.

DATA Brake disc thickness


Service limit (Front): 2.5 mm (0.10 in)
(Rear): 3.5 mm (0.14 in)



- Measure the front and rear brake disc runout.

DATA Brake disc runout

Service limit: 0.30 mm (0.012 in)



BRAKE DISC REPLACEMENT (C14-5)

CALIPER

▲ WARNING

The use of any brake fluid except DOT4 brake fluid from a sealed container can damage the brake system and lead to an accident.

Use only DOT4 brake fluid from a sealed container. Never use or mix different types of brake fluid.

▲ WARNING

Brake fluid can be hazardous to humans and pets. Brake fluid is harmful or fatal if swallowed, and harmful if it comes in contact with your skin or eyes.

Keep brake fluid away from children. Call your doctor immediately if brake fluid is swallowed, and induce vomiting. Flush eyes or skin with water if brake fluid gets in eyes or comes in contact with skin.

CAUTION

Spilled brake fluid can damage painted surfaces and plastic parts.

Be careful not to spill any fluid when servicing the caliper. Wipe spilled fluid up immediately.

FRONT CALIPER REMOVAL AND DISASSEMBLY

- Drain brake fluid. (☞ 15-4)
 - Place a rag under the brake hose union bolt ① to catch spilled brake fluid.
 - Remove the caliper mounting bolts ②.
-
- Remove the brake pads (☞ 15-5) and spring from the caliper.
 - Remove the caliper bracket from the caliper.
 - Remove the boots from the caliper bracket.
-
- Wrap the caliper with a rag to prevent brake fluid scatter and piston pop-out.
 - Apply low-pressure air into the caliper through the hole to remove the pistons.

▲ WARNING

Fingers can get caught between piston and caliper body when removing the piston.

Do not place your fingers on the piston when removing the piston.

- Remove the pistons ① and the dust seals ② and piston seals ③.




REAR CALIPER REMOVAL AND DISASSEMBLY

- Place a block under the chassis tubes.
- Remove the rear wheel (☞ 14-6)
- Drain brake fluid. (☞ 15-4)
- Place a rag under the brake hose union bolt to catch spilled brake fluid.
- Disconnect the brake hose.
- Remove the caliper.
- Remove the caliper protector ① and disc cover ②.



- Remove the cap and brake pad mounting pin ③.
- Remove the brake pad ④. (☞ 15-5)
- Remove the boots ⑤.
- Remove the pad spring ⑥.



- Wrap the caliper with a rag to prevent brake fluid scatter and piston pop-out.
- Apply low-pressure air into the caliper through the hole to remove the piston.

▲ WARNING

Fingers can get caught between piston and caliper body when removing the piston.

Do not place your fingers on the piston when removing the piston.



- Remove the piston seal and dust seal.

CALIPER INSPECTION


- Inspect the caliper cylinder for scuffing.
- Inspect the caliper piston for scuffing.

CALIPER CLEANING

- Flush the caliper ports with pressurized air.
- Wash the caliper piston and cylinder with fresh brake fluid.

NOTE:


Do not use gasoline or other cleaning solvents to wash the caliper parts.



FRONT CALIPER REASSEMBLY


Reassemble and remount the brake caliper in the reverse order of removal. Pay attention to the following points:

- Apply brake fluid to the piston seals, dust seals and pistons and fit the piston seals, dust seals and pistons.

 Specification and classification: DOT4




- Fit the caliper brackets and pad springs.
- Apply SUZUKI SILICONE GREASE to the caliper axles.

 99000-25100: SUZUKI SILICONE GREASE


- Fit the brake pads. Tighten the brake pad mounting bolt temporarily.




- Tighten the caliper mounting bolts to the specified torque.

 Brake caliper mounting bolt (1):
26 N·m (2.6 kgf-m, 18.9 lb-ft)

- Tighten the brake pad mounting pin (2) to the specified torque.

 Brake pad mounting pin (2):
17.5 N·m (1.75 kgf-m, 13.2 lb-ft)

- Tighten the brake hose Union bolt to the specified torque.

 Brake hose union bolt (3): 23 N·m (2.3 kgf-m, 16.5 lb-ft)

- Refill brake fluid and bleed air from the brake system. (C-15-4)



REAR CALIPER REASSEMBLY


Reassemble and remount the brake caliper in the reverse order of removal. Pay attention to the following points:

- Apply brake fluid to the piston seal and fit the piston seal and dust seal.

 **Specification and classification: DOT4**




- Apply SUZUKI SILICONE GREASE to the caliper axle.

 **99000-25100: SUZUKI SILICONE GREASE**




- Tighten the brake pad mounting bolt (1) to the specified torque.

 **Brake pad mounting bolt:**

17.5 N·m (1.75 kgf-m, 13.2 lb-ft)

- Tighten the brake hose union bolt (2).

 **Brake hose union bolt: 23 N·m (2.3 kgf-m, 16.5 lb-ft)**

- Refill brake fluid and bleed air from the brake system. (C-15-4)



MASTER CYLINDER

▲ WARNING

Brake fluid can be hazardous to humans and pets. Brake fluid is harmful or fatal if swallowed, and harmful if it comes in contact with your skin or eyes.

Keep brake fluid away from children. Call your doctor immediately if brake fluid is swallowed, and induce vomiting. Flush eyes or skin with water if brake fluid gets in eyes or comes in contact with skin.

▲ WARNING

The use of any fluid except DOT4 brake fluid from a sealed container can damage the brake system and lead to an accident.

Use only DOT4 brake fluid from a sealed container. Never use or mix different types of brake fluid.

CAUTION

Spilled brake fluid can damage painted surfaces and plastic parts.

Be careful not to spill any fluid when filling the brake fluid reservoir. Wipe spilled fluid up immediately.

FRONT MASTER CYLINDER REMOVAL AND DISASSEMBLY

- Drain brake fluid (☞ 15-4)
- Place a rag under the brake hose union bolt to catch spilled brake fluid.
- Disconnect the brake hose.
- Remove the master cylinder holder bolts.

- Remove the master cylinder cap.
- Remove the bolt and brake lever.



- Remove the brake lever adjuster return spring (1).



- Remove the diaphragm.
- Remove the dust seal boot (1).
- Remove the snap ring (2) with snap ring pliers.
- Remove the washer (3), piston (4) and spring (5).

 09900-06106: Snap ring pliers




REAR MASTER CYLINDER REMOVAL AND DISASSEMBLY

- Drain brake fluid. (C7 15 4)
- Place a rag under the hose to catch spilled brake fluid.
- Remove the brake hose union bolt.
- Remove the master cylinder mounting bolts.



- Remove the master cylinder cap.
- Remove the diaphragm.
- Remove the dust seal boot (1).
- Remove the snap ring (2) with snap ring pliers.
- Remove the push rod (3).
- Remove the piston/cup set (4).

 09900-06106: Snap ring pliers



MASTER CYLINDER INSPECTION

- Inspect the cylinder bore and piston for scuffing.
- Inspect the piston rod and spring for damage.



MASTER CYLINDER CLEANING

- Flush the master cylinder ports with pressurized air.
- Wash the master cylinder bore and piston with fresh brake fluid.

NOTE:

Do not use gasoline or other cleaning solvents to wash the master cylinder parts.






FRONT MASTER CYLINDER REASSEMBLY

Reassemble and remount the master cylinder in the reverse order of removal and disassembly. Pay attention to the following points:

- Temporarily tighten the master cylinder mounting bolts.

NOTE:

When remounting the master cylinder onto the handlebar, align the master cylinder holder's mating surface  with the punch mark  on the handlebar and tighten the upper bolt first.



- Tighten the master cylinder mounting bolts to the specified torque.

Master cylinder mounting bolt ①:
10 N·m (1.0 kgf-m, 7.0 lb-ft)

- Tighten the brake hose union bolt to the specified torque.

Brake hose union bolt ②: 23 N·m (2.3 kgf-m, 16.5 lb-ft)

- Refill brake fluid and bleed air from the brake system. (CJ15-4)



REAR MASTER CYLINDER REASSEMBLY

Reassemble and remount the master cylinder in the reverse order of removal and disassembly. Pay attention to the following points:

- Tighten the master cylinder mounting bolts ① to the specified torque.

Master cylinder mounting bolt:
10 N·m (1.0 kgf-m, 7.0 lb-ft)

- Tighten the brake hose union bolt ② to the specified torque.

Brake hose union bolt: 23 N·m (2.3 kgf-m, 16.5 lb-ft)



CAUTION

Improper brake hose routing can damage the brake hose.

Set the brake hose so it touches the stopper and tighten the union bolt. Ensure the brake hose has enough clearance to the rear suspension spring.

- Refill brake fluid and bleed air from the brake system. (CJ15-4)

BRAKE PEDAL


REMOVAL



- Remove the cotter pin ① and brake pedal pivot bolt.
- Remove the return spring.
- Remove the cotter pin ②, washer and pin.



REASSEMBLY

- Fit the return spring properly.
- Apply SUZUKI SUPER GREASE to the brake pedal pivot bolt.

 99000-25030: SUZUKI SUPER GREASE "A" (USA)
99000-25010: SUZUKI SUPER GREASE "A" (Others)

- Tighten the brake pedal pivot bolt to the specified torque.
-  Brake pedal pivot bolt: 29 N·m (2.9 kgf-m, 21.0 lb-ft)
- Install new cotter pins.
 - Adjust the brake pedal height. ( 2-19)




SAMPLE

FRONT FORK AND STEERING


CONTENTS

CONSTRUCTION	16- 2
FRONT FORK, STEERING	16- 2
HANDLEBAR CONTROLS	16- 3
FRONT FORK	16- 4
REMOVAL	16- 4
DISASSEMBLY	16- 5
INSPECTION	16- 9
REASSEMBLY	16-11
INSTALLATION	16-16
STEERING	16-18
REMOVAL	16-18
INSPECTION	16-19
BEARING REPLACEMENT	16-20
INSTALLATION	16-20

CONSTRUCTION FRONT FORK, STEERING



HANDLEBAR CONTROLS



FRONT FORK

REMOVAL

- Place the motorcycle on a block to lift front wheel off the ground.
 - Remove the front wheel. (☐ 14-3)
 - Remove the front number plate.
 - Remove the handlebar holder bolts.
-
- Remove the fork protectors, brake hose guide and brake hose clamp.
 - Remove the front brake caliper.



- Loosen the front fork cap bolt 1 – 2 turns to facilitate later disassembly.

 09941-53630: Front fork top cap wrench

- Loosen the front fork upper clamp bolts (1).



- Hold the fork body and loosen the fork lower clamp bolts (2).
- Remove the front fork.



DISASSEMBLY

- Set rebound and compression damper settings to the minimum settings (softest) before disassembling. Record the setting before turning the adjuster.
- Thoroughly clean the fork before disassembly.

CAUTION

Scratches or other damage on the inner tube or on the oil seal lip will cause oil leak.

Avoid scratching or damaging the inner tube or the oil seal. Use a mild detergent or car wash soap and sponge out dirt with plenty of water.

- Clamp the outer tube with a vise. Protect the outer tube with a rag when using a vise.
- Loosen and remove the fork cap bolt (sub-tank) from the outer tube and slowly slide down the outer tube.


 09941-53630: Front fork top cap wrench




- Place a drain pan under the front fork and drain fork oil.

NOTE:

Face the oil hole  on the sub-tank downward.



- Raise the outer tube and temporarily install the fork cap bolt  (sub-tank) to the outer tube.



- Clamp the axle holder ② with a vise. Protect the axle holder with a rag when using a vise.
- Loosen the carrier bolt ③ completely with a 21 mm socket wrench.

⚠ WARNING

Clamping the axle holder too tight can damage it which will affect riding stability.

Do not clamp the axle holder too tight.



- Compress the outer tube by hands and install the conrod holder (special tool) between the axle holder bottom ② and locknut ④.

 08910-20115: Conrod holder



- Hold the locknut with a wrench and remove the center bolt.



- Remove the push rod.



- With the outer tube compressed by hands, remove the special tool

CAUTION

Removing the locknut ④ and pushing the inner rod thread into the damper rod will damage the inner rod oil seal.

Do not remove the locknut ④ from the inner rod.




- Loosen the fork cap bolt ① (sub-tank) and remove the sub-tank ⑤ along with the damper rod assembly ⑥.
- Remove the fork spring ⑦ and spring collar ⑧.

CAUTION

Disassembling the damper rod assembly can lead to trouble.

Do not disassemble the damper rod assembly.
Do not separate the sub-tank and damper rod assembly.



- Remove the dust seal ⑨ and the stopper ring ⑩.

CAUTION

Scratches on the inner tube could cause oil leaks.

Avoid scratching when removing.



INNER TUBE

- Separate the inner tube out of the outer tube.



- Remove the slide bushing from the inner tube.



- Remove the following parts from the inner tube:


Guide bushing ①

Seal retainer ②

Oil seal ③

Stopper ring ④

Dust seal ⑤



- Clamp the bottom (fat part) of the sub-tank with a vise.

CAUTION

Do not clamp the sub-tank too tight.



- Loosen the compression damper unit.



- Remove the compression damper unit from the sub-tank.

NOTE:

Slowly compress the inner rod until it stops so that the compression damper unit can be removed easily.

**CAUTION**

Disassembling the compression damper unit can lead to trouble.

Do not disassemble the compression damper unit.



- Drain the fork oil from the damper rod assembly by moving the inner rod several strokes.

**INSPECTION****CENTER BOLT**

- Inspect the adjuster rod of the center bolt for damage. If it is damaged, replace it with a new one.
- Replace the O-ring with a new one.

**COMPRESSION DAMPER UNIT**

- Inspect the compression damper unit for damage. If it is damaged, replace it with a new one.
- Replace the O-ring with a new one.



INNER TUBE AND OUTER TUBE

- Inspect the inner tube for scratches. If it has scratches, replace it with a new one.
- Inspect the outer tube for dent. If it is dented all the way to the inner side, replace it with a new one.



- Measure the inner tube runout using the V-blocks and dial gauge.


INSTRUMENT Inner tube runout

Service Limit: 0.4 mm (0.02 in)

INSTRUMENT 09900-20607: Dial gauge (1/100)

09900-20701: Magnetic stand

09900-21304: V-block

**DAMPER ROD**


- Inspect the damper rod assembly for scratches or bending. If it has scratches or is bent, replace it with a new one.

**SPRING COLLER**

- Inspect the spring collar. If any damage is found, replace it with a new one.

**FORK SPRING**

- Measure the free length of front fork spring.

INSTRUMENT Service Limit: 487 mm (19.17 in)

SLIDE BUSHING AND GUIDE BUSHING

Inspect the "teflon coating metals" (slide bushing and guide bushing) for wear or damage. If they are worn or damaged, replace them with new ones.


Inspect the metal particles on the "teflon coating metals". If they are not clean, clean them with a nylon brush and fork oil.

**REASSEMBLY****NOTE:**

- * Clean all fork parts before reassembling.
- * Replace the O-rings, oil seal and dust seal with the new ones.
- * Apply specified front fork oil when installing the O-rings, slide bushing, guide bushing, damper unit and other sliding parts.

INNER TUBE

- Apply front fork oil to the oil seal lip and the dust seal.
- Cover the inner tube with a plastic film.
- Install the following parts to the inner tube:
 New dust seal ①
 Stopper ring ②
 New oil seal ③

**CAUTION**

Scratches on the oil seal lip can cause oil leaks.

When installing the seal, place a plastic film over the bushing attachment groove and edges of the inner tube to avoid damage to the seal lip.

NOTE:

The side of the oil seal that has a mark should face the dust seal.

- Remove the plastic film and then install the seal retainer ④, guide bushing ⑤ and slide bushing ⑥.
- Clean the parts and keep them free from dust.

NOTE:

Inspect the bushings for burrs. If there is a burr, remove it with a knife, taking care not to peel off the teflon coating. If the bushings have a large crack or excessive play after installing them, replace them with the new ones.


- Insert the inner tube into the outer tube.



- Install the new oil seal (3) with the special tool until the stopper ring groove of the outer tube can be seen.

TOY 08940-52861: Front fork oil seal installer set


- Attach the stopper ring securely to the stopper ring groove of the outer tube.



- Attach the dust seal (1).

NOTE:

After attaching the dust seal, make sure that there are no cracks around the circumference of the seal. Cracks could allow water, mud and the like to enter and cause an oil leak.



CAUTION

Use of grease as a substitute fork oil when installing the oil seal can result in an oil leak. Applying grease to the dust seal and oil seal can cause dirt to accumulate and damage the dust seal lip and oil seal lip.

Use only a thin coat of fork oil on the oil seal.

COMPRESSION DAMPER UNIT

NOTE:

Clean each threaded part before installing.



- With the damper rod in fully extended position, pour the specified amount of fork oil.

DATA Fork oil quantity (inside the damper rod):
180 ml (6.00/6.34 US/Imp oz)

TOY 99000-99001-555: SUZUKI FORK OIL 55-05



- Apply fork oil to the O-rings and bushing on the compression damper unit.
- With the damper rod held immovable in fully extended position, gently install the compression damper unit to the sub-tank.




- Clamp the bottom (flat part) of the sub-tank with a vise.

CAUTION

Do not clamp the sub-tank too tight.

- Tighten the compression damper unit to the specified torque.


 **Compression damper unit: 30 N·m (3.0 kgf-m, 21.5 lb-ft)**



- With the damper rod held in vertical position, slowly move the inner rod several strokes.



- Tighten the locknut by hand completely.



- With the damper rod held in vertical position, compress the damper rod fully to discharge an excess of oil.

CAUTION

Protect the inner rod end with a rag when compressing the damper rod.

NOTE:

Set the compression damper setting to the softest.



- Force out the remaining oil (discharged oil) using compressed air completely.




- With the damper rod in horizontal position, move the inner rod by hand to inspect if it operating smoothly.

If the inner rod is not extend, repeat the "COMPRESSION DAMPER UNIT" procedures (Pour the specified amount fork oil and discharge an excess of oil). (C/P16-12)



- Make sure approx. 10 mm (0.39 in) of inner rod thread is exposed on the end.



- Completely wipe off the fork oil from the spring and damper rod assembly.
- Insert the spring and damper rod assembly into the fork.



- Temporarily tighten the fork cap bolt (sub-tank).

 08941-53630: Front fork top cap wrench



- Clamp the axle holder with a vise. Protect the axle holder with a rag when using a vise.


▲ WARNING

Clamping the axle holder too tight can damage it which will affect riding stability.

Do not clamp the axle holder too tight.

- Compress the outer tube by hands and install the conrod holder (special tool) between the axle holder bottom and locknut.

09910-20118: Conrod holder


- Insert the push rod into the inner rod.
- Insert the  shaped projection of center bolt into the push rod.

- Slowly turn the center bolt clockwise until resistance is felt and check the clearance between the locknut and center bolt to provide more than 1 mm (0.04 in).

- Turn the locknut counterclockwise until it contacts with the center bolt.
- With the locknut held immovable using a wrench, tighten the locknut/center bolt to the specified torque.

🔧 Locknut/center bolt: 22 N·m (2.2 kgf-m, 16.0 lb-ft)

- With the outer tube compressed by hands, remove the special tool.



- Tighten the center bolt to the specified torque.


 Center bolt: 70 N·m (7.0 kgf-m, 51.0 lb-ft)



- Loosen and remove the fork cap bolt (sub-tank) from the outer tube and slowly slide down the outer tube.

 09941-53630: Front fork top cap wrench

- Pour the specified amount of fork oil into the outer tube.

 Oil quantity (When standard fork spring is used):
373 ml (12.61/13.13 US/Imp oz)

 99000-99001-SS6: SUZUKI FORK OIL SS-05



- Raise the outer tube and temporarily tighten the fork cap bolt (sub-tank).

 09941-53630: Front fork top cap wrench




INSTALLATION

- Set the aligning line ① on the outer tube to the upper surface of the upper bracket.
- Check that the air valve ② is positioned at the front.




- Tighten the fork lower clamp bolts to the specified torque.

 Fork lower clamp bolt: 23 N·m (2.3 kgf-m, 16.5 lb-ft)




- Tighten the fork upper clamp bolts to the specified torque.

 Fork upper clamp bolt: 23 N·m (2.3 kgf-m, 16.5 lb-ft)


- Tighten the fork cap bolt (sub-tank) to the specified torque.

 09941-53630 : Front fork top cap wrench

 Fork cap bolt: 35 N·m (3.5 kgf-m, 25.5 lb-ft)

- Install the handlebars. ( 16-22)

- Install the front wheel. ( 14-5)

- Install the brake caliper. ( 15-9)

- Check that the front fork protector moves smoothly. If not, loosen and adjust the protector guide.



SAMPLE

STEERING

REMOVAL

HANDLEBARS

- Place a block under the chassis tube.
 - Remove the clutch lever.
 - Remove the engine stop switch (1).
 - Remove the clamps.
-
- Remove the front brake master cylinder.
-
- Loosen the throttle assembly mounting bolts.
-
- Remove the front number plate.
 - Remove the handlebar holder bolts and remove the handlebars.



STEERING STEM

- Remove the front wheel. (14-3)
- Remove the front forks. (16-4)




- Remove the front fender.



- Remove the steering stem head nut.
- Remove the upper bracket.



- Remove the steering nut with the special tools:
 09940-14911: Steering nut socket wrench
 09940-14960: Attachment

- Remove the steering stem.

**INSPECTION**

- Inspect the bearing races for wear.
- Inspect the needle bearings for wear.
- Inspect the steering stem for distortion.



BEARING REPLACEMENT

NOTE:

Replace the outer race and bearing as a set.

- Remove the upper and lower outer races with the special tools.


 09941-34911: Steering race remover
09941-74911: Steering bearing installer



- Removes the lower bearing.

- Fit the lower bearing with the special tools.

 09925-16011: Steering bearing installer

- Fit the upper and lower outer races with the special tools.


 09941-34513: Steering outer race and swingarm bearing installer
09924-84510: Bearing installer



INSTALLATION

STEERING STEM


- Apply grease to the bearings.
- Fit the steering stem, upper bearing and steering stem nut.
- Tighten the steering stem nut with the special tool.

 09940-14911: Steering nut socket wrench
09940-14960: Attachment

 Steering stem nut: 45 N·m (4,5 kgf-m, 32,5 lb-ft)



- Move the steering stem right and left several times to seat the bearings.
- Turn back the steering stem nut by 1/4 to 1/2 turn.
- Fit the steering stem head nut and tighten it temporarily.
- Remount the front forks. (☞ 18-16)




- Tighten the steering stem head nut to the specified torque.

🔧 Steering stem head nut: 100 N·m (10.0 kgf·m, 72.5 lb-ft)



HANDLEBARS


- Apply adhesive agent to the left handlebar end and inside of the left grip.



- Align the "Δ" mark on the left grip with the punched mark ⊗ on the left handlebar end.




- Align the "Δ" mark on the throttle grip with the hole on the throttle rotor.



- Align the punched mark (⊙) on the handlebars with the throttle holder matching surface.



- Set the punched mark on the handlebar holder forward.



- Align the punched mark (⊙) on the handlebars with the matching surface of the handlebar holder.
- Tighten the handlebar clamp bolts to the specified torque.

🔧 Handlebar clamp bolt: 25 N·m (2.5 kgf·m, 18.0 lb-ft)

NOTE:


When tightening the handlebar clamp bolts, first tighten the bolts (⊙).



- Align the punched mark (⊙) on the handlebars with the front brake master cylinder matching surface.



- Align the punched mark **E** on the handlebars with the clutch lever holder matching surface.
- Install the engine stop switch.



Inspect the following items.

- Front fork (☞ 2-20)
- Steering (☞ 2-21)
- Wire, cable and hose routing (☞ 18-10, 11)


SAMPLE

REAR SUSPENSION

CONTENTS

CONSTRUCTION	17- 2
REAR SUSPENSION	17- 2
REAR SHOCK ABSORBER	17- 3
REMOVAL	17- 3
SPRING REPLACEMENT	17- 4
INSPECTION	17- 5
BEARING REPLACEMENT	17- 5
OIL REPLACEMENT	17- 6
DISASSEMBLY AND INSPECTION	17- 9
REASSEMBLY	17-11
INSTALLATION	17-11
DISPOSAL	17-12
SWINGARM	17-13
REMOVAL	17-13
INSPECTION	17-14
BEARING REPLACEMENT	17-15
INSTALLATION	17-16
REAR SUSPENSION LINKAGE	17-17
REMOVAL	17-17
INSPECTION	17-17
BEARING REPLACEMENT	17-18
REASSEMBLY	17-19

CONSTRUCTION REAR SUSPENSION



REAR SHOCK ABSORBER

REMOVAL

- Place a block under chassis tubes.
- Remove the seat. (C75-3)
- Loosen the air cleaner clamp screw.
- Remove the right frame cover. (C75-2)
- Remove the silencer and rear frame assembly.
- Remove the rear shock absorber upper mounting bolt and nut.



- Lifting up the swingarm, remove the rear shock absorber lower mounting bolt and nut.
- Remove the rear shock absorber.




SPRING REPLACEMENT

- Loosen the locknut ① with the special tool and turn it fully to the end of the thread.
- Turn the adjuster ② as well as the locknut ①.

COO 09910-60611: Universal clamp wrench




- Depress the spring seat ③ and remove the stopper ring ④.
- Remove the spring seat ③ and the spring ⑤ from the rear shock absorber.



- Install the locknut, adjuster, spring, spring seat and stopper ring.

NOTE:

Install the spring as its painted side ⑥ or small diameter side faces bottom.



- Adjust the spring set length and tighten the locknut.

DATA Standard spring set length:
6.7 mm (0.264 in) compressed from the free length
Spring set length adjustable range:
1 – 15 mm (0.039 – 0.591 in)
③: Standard spring set length
⑤: Spring free length



INSPECTION

- Inspect the rear shock absorber for oil leakage.
- Inspect the damper rod for bends and smooth movement.
- Inspect the bump rubber for deterioration and damage.
- Inspect the damper rod hidden by the bump rubber by moving the bump rubber.



- Inspect the spacers and dust seals for damage.
- Inspect the bearing for excessive play and smooth movement.

**BEARING REPLACEMENT**

- Remove the needle roller bearings ①.
- Remove the dust seals ②.



- Remove the needle roller bearing cage ③ with the special tool.


 09921-20240: Bearing remover set



- Press the bearing cage with the special tool and a suitable size socket wrench.

NOTE:

Position the bearing by referring to the illustration of page 17-20.

 09924-84521: Bearing installer set



- Install the dust seals.

NOTE:

When installing the dust seal, the stamped mark on the dust seal must face inside.




- Apply grease to the needle roller bearings and install them.
- Apply grease to the dust seals and spacers.
- Install the spacers (K) and (L).
- (K) for Right side
- (L) for Left side

ACOH 99000-25030: SUZUKI SUPER GREASE "A" (USA)
99000-25010: SUZUKI SUPER GREASE "A" (Others)

**OIL REPLACEMENT****TOOLS AND EQUIPMENT**

- Following tools and equipment are required to perform oil replacement.



- | | |
|--------------------------------|-----------------------------|
| (1) Screwdriver or small punch | (6) Flange |
| (2) Vise* | (7) Nitrogen tank |
| (3) Drain Pan | (8) Filler Hose and Nozzle |
| (4) Oilcan | (9) Regulator Assembly |
| (5) Bucket | (10) Owner's Service Manual |
| (6) Specified Shock Oil (SS25) | |

* Not Shown in the Illustration

OIL REPLACEMENT PROCEDURE

- Remove the rear shock absorber unit from the frame (17-3), clean and dry it.
- Remove the spring from the rear shock absorber unit. (17-4)

NOTE:

Inspect the rear shock absorber unit for oil leak.

Turn the rebound damping force adjuster screw counterclockwise until it stops so that the rear suspension oil can be poured easily.

- Remove the valve cap. Press the valve with a screwdriver to bleed out nitrogen gas.

▲ WARNING

Releasing high pressure gas from the rear shock absorber unit can be hazardous.

Never perform any servicing until the nitrogen gas pressure has been released from the rear shock absorber unit. When releasing the gas pressure, place a rag over the gas valve and use the tip of a screwdriver etc. to press the valve. Do not use your finger to depress the gas valve, and direct the valve away from your face and body.

- Remove the compression adjuster assembly (1) from the rear shock absorber.


- Place a drain pan under the rear shock absorber unit.
- Move the rod and drain the oil completely.
- Push the valve core again to equalize the bladder to atmospheric pressure.




- Pour the fresh specified rear suspension oil as shown while moving the rod.


NOTE:

Be sure to extend the rod after filling the oil.



- Tilt the shock absorber unit as shown and pour the fresh rear suspension oil fully into the reservoir tank.

 99000-99001-S25: SUZUKI REAR SUSPENSION OIL
SS-25

 Oil capacity: Approx. 380 ml (12.84/13.38 US/Imp oz)



- Cover the compression adjuster hole with the rod of your thumb.
- Tilt and shake the rear shock absorber unit to fill the reservoir tank with the oil.
- Add the oil and repeat the above procedure until the reservoir tank is filled with the oil completely.



- Replace the O-rings on the compression adjuster assembly with new ones.



- Reinstall the compression adjuster assembly.

Compression adjuster assembly:

30 N·m (3.0 kgf-m, 21.5 lb-ft)

- Fill the rear shock absorber unit with nitrogen gas to 881 kPa (9.8 kgf/cm², 129.5 psi).
- Tighten the gas valve cap.
- Reinstall the spring. (☞17-4)



WARNING

Use of flammable gas for pressuring the rear shock absorber unit can be hazardous. Flammable gas such as gas welding oxygen can cause a fire hazard.

Use nitrogen gas. If nitrogen gas is not available, compressed air free from water can be substituted.

WARNING

Applying too much pressure to the rear shock absorber unit may rupture the rear shock absorber unit.

Be sure to fill the rear shock absorber unit to the specified pressure.

CAUTION

Riding the motorcycle with abnormal gas pressure can damage the rear shock absorber unit. Low gas pressure can result in oil leakage. Abnormal gas pressure cannot provide normal rear shock absorber unit performance.

Be sure to fill the rear shock absorber unit to the specified pressure.

DISASSEMBLY AND INSPECTION

- Clean and dry the rear shock absorber.
- Remove the spring from the rear shock absorber. (☞17-4)
- Turn the rebound damping force adjuster to the softest position.
- Press the valve with a screwdriver to bleed out nitrogen gas. (☞17-7)
- Remove the compression adjuster assembly and drain the oil. (☞17-7)



- Vise the rear shock absorber unit in inverted position.
- Depress the bump rubber fully to protect the damper rod.



- Evenly hammer the stopper (1) with a screwdriver or equivalent and remove it from the rear shock absorber body.



- Depress the seal base (2) with a screwdriver until the circlip (3) is fully exposed.



- Remove the circlip (3)

NOTE:

Do not scratch the inner surface of the shock absorber body to avoid oil leaks.



- Extract the damper rod assembly from the shock absorber body.
- Inspect the oil seal and C-rings.
- Inspect the damper rod for bends and scratches.
- Inspect the inner surface of the body.
- Inspect the "teflon coating metal" on the piston.
- Replace C-rings with new ones.
- Replace the "teflon coating metal" by cutting off the old one and putting a new one onto the piston if necessary.



REASSEMBLY

- Apply the rear suspension oil to the O-rings and the "titanium coating metal".
- Insert the damper rod assembly ① and fit a new circlip ②.
- Pull up the damper rod assembly ① until it is stopped by the circlip ②.
- Fit the stopper to the shock absorber body.
- Fill the specified rear suspension oil in the rear shock absorber. (☞ 17-8)



99000-99001-825: SUZUKI REAR SUSPENSION OIL
SS-25

NOTE Oil capacity: Approx. 380 ml (12.84/13.38 US/Imp oz)

- Reinstall the compression adjuster assembly. (☞ 17-8)
- Pressure the rear shock absorber unit with nitrogen gas to 981 kPa (9.8 kgf/cm², 130.5 psi). (☞ 17-9)
- Reassemble the spring and adjust the spring set length. (☞ 17-4)
- Tighten the valve cap.

INSTALLATION

Install the rear shock absorber in the reverse order of removal. Pay attention to the following points:

- Lifting up the swingarm, install the rear shock absorber to the cushion lever.
- Tighten the lower mounting bolt and nut to the specified torque.



☑ Rear shock absorber lower mounting nut:
60 N·m (6.0 kgf-m, 43.5 lb-ft)

- Tighten the upper mounting bolt and nut to the specified torque.

☑ Rear shock absorber upper mounting nut:
60 N·m (6.0 kgf-m, 43.5 lb-ft)



DISPOSAL

High pressure nitrogen gas is sealed in the rear shock absorber unit. Be sure to release gas before disposing the rear shock absorber unit.

- Remove the valve cap.



- Press the valve with a screwdriver.

▲ WARNING

Releasing high pressure gas from the rear shock absorber unit can be hazardous.

Place a rag over the valve and push the valve with a screwdriver to release nitrogen gas. Do not use your finger to push the valve, and direct the valve away from your face and body.



SAMPLE

SWINGARM

REMOVAL

- Place a block under the chassis tubes.
- Remove the rear wheel. (REF 14-6)
- Remove the chain guide.



- Remove the rear brake hose guide.
- Remove the rear brake caliper.



- Remove the rear cushion lever bolt and nut.



- Remove the swingarm pivot nut and shaft.
- Remove the swingarm.



- Remove the chain buffer.



- Remove the following parts from the swingarm:

- Spacer ①
- Dust seal ②
- Washer ③
- Thrust bearing ④
- Dust seal ⑤
- Spacer ⑥



INSPECTION

- Measure the pivot shaft runout with the dial gauge and V-blocks.


Swingarm pivot shaft runout

Service Limit: 0.3 mm (0.01 in)

09900-20606: Dial gauge (1/100 mm)

09900-20701: Magnetic stand

09900-21304: V-block set (100 mm)




- Inspect the chain buffer for damage and excessive wear.



- Inspect the swingarm for cracks and damage.



- Inspect the bearings, spacers and oil seals for damage.




- Insert the spacers into the bearings and inspect them for play and smooth movement.



BEARING REPLACEMENT

- Remove the bearings with the special tools.


 09923-74511: Bearing remover
09930-30104: Sliding shaft



- Press fit the bearing with the special tool.

 09913-70210: Bearing installer set

- Apply grease to the bearings.

 99000-25030: SUZUKI SUPER GREASE "A" (USA)
99000-25010: SUZUKI SUPER GREASE "A" (Others)



INSTALLATION

- Reassemble the following parts into the swingarm.

- | | |
|------------------|-------------|
| ① Dust seal | ⑤ Washer |
| ② Spacer | ⑥ Dust seal |
| ③ Washer | ⑦ Spacer |
| ④ Thrust bearing | |

- Apply grease to the dust seals, bearings and spacers.

⚠ 99000-25030: SUZUKI SUPER GREASE "A" (USA)
99000-26010: SUZUKI SUPER GREASE "A" (Others)

- Reassemble the chain guide.
- Tighten the swingarm pivot nut to the specified torque.

⚠ Swingarm pivot nut: 70 N·m (7.0 kgf-m, 51.0 lb-ft)



- Tighten the rear cushion rod nut to the specified torque.

⚠ Rear cushion rod nut: 80 N·m (8.0 kgf-m, 58.0 lb-ft)

- Install the rear brake caliper. (☞ 15-10)
- Install the rear wheel. (☞ 14-8)
- Adjust the drive chain slack. (☞ 2-18)



REAR SUSPENSION LINKAGE

REMOVAL

- Place a block under the chassis tubes
- Remove the lower drive chain control roller ①.



- Remove the rear cushion rod bolt and nut.
- Remove the cushion lever bolts and nuts.
- Remove the shock absorber lower bolt and nut.



- Remove the cushion rod from the cushion lever.
- Remove the spacers.



INSPECTION

- Inspect the cushion rod and cushion lever for damage.
- Inspect the dust seals and spacers for damage.



- Insert the spacers into the bearings and inspect them for play and smooth movement.




BEARING REPLACEMENT

- Remove the spacers and dust seals.
- Remove the needle roller bearings.



- Remove the needle roller bearing cage ① with the special tool.


 08921-20240: Bearing remover set



- Press fit the bearing with the special tool.

 08913-70210: Bearing installer set

- Apply grease to the bearings.

 99000-25030: SUZUKI SUPER GREASE "A" (USA)
99000-25010: SUZUKI SUPER GREASE "A" (Others)




- Press fit the bearing cage with the special tool and a suitable size socket wrench.

 09924-84521: Bearing installer set

NOTE:

Position the bearings by referring to the illustration of page 17-20.

- Apply grease to the bearings.


 99000-25030: SUZUKI SUPER GREASE "A" (USA)
99000-25010: SUZUKI SUPER GREASE "A" (Others)



REASSEMBLY

Reassemble and remount the rear suspension linkage in the reverse order of removal and disassembly. Pay attention to the following points:


- Position the dust seals (1) so that the manufacturer's code indicated side of the seals face outside. (2: inside)
- Apply grease to the spacers and dust seals.

 99000-25030: SUZUKI SUPER GREASE "A" (USA)
99000-25010: SUZUKI SUPER GREASE "A" (Others)




SAMPLE

- Tighten the cushion lever, cushion rod and swingarm nuts to the specified torque:



F Tightening torque:

- Ⓐ: 60 N·m (6.0 kgf·m, 43.5 lb-ft)
- Ⓑ: 60 N·m (6.0 kgf·m, 43.5 lb-ft)
- Ⓒ: 80 N·m (8.0 kgf·m, 58.0 lb-ft)
- Ⓓ: 80 N·m (8.0 kgf·m, 58.0 lb-ft)
- Ⓔ: 80 N·m (8.0 kgf·m, 58.0 lb-ft)
- Ⓕ: 70 N·m (7.0 kgf·m, 50.5 lb-ft)

**CAUTION**

Improperly reassembled rear suspension linkage bolts can interfere with suspension movement and damage the rear suspension linkage.

- * Make sure that the rear shock absorber rebound damping adjuster on the bottom bracket of the rear shock absorber is located to the right side.
- * Insert the rear suspension linkage bolt ① from the left side. Make sure that the nut ② is in the recess of the rear shock absorber bottom bracket.

SERVICING INFORMATION

CONTENTS

SERVICE DATA	18- 2
CYLINDER + PISTON + PISTON RING	18- 2
CONROD + CRANKSHAFT	18- 2
CLUTCH	18- 2
RADIATOR	18- 3
TRANSMISSION	18- 3
DRIVE CHAIN	18- 3
CARBURETOR	18- 3
ELECTRICAL	18- 4
BRAKE + WHEEL	18- 4
SUSPENSION	18- 5
TIRE PRESSURE	18- 5
FUEL + OIL + COOLANT	18- 6
SPECIAL TOOLS	18- 7
WIRING DIAGRAM	18- 9
WIRE, CABLE AND HOSE ROUTING	18-10
SPECIFICATIONS	18-19
DIMENSIONS AND DRY MASS	18-19
ENGINE	18-19
TRANSMISSION	18-19
CHASSIS	18-20
ELECTRICAL	18-20
CAPACITIES	18-20
SPARE PARTS LIST	18-21
OPTIONAL PARTS	18-21
REAR SPROKET	18-21

SERVICE DATA

CYLINDER + PISTON + PISTON RING

Unit: mm (in)

ITEM	STANDARD	LIMIT
Piston to cylinder clearance	0.030 – 0.040 (0.0012 – 0.0016)	0.120 (0.0047)
Cylinder bore	54.000 – 54.015 (2.1260 – 2.1266) Measure 20 (0.79) from the top surface.	—
Piston diam.	53.985 – 53.980 (2.1246 – 2.1252) Measure 19 (0.75) from the skirt end.	53.880 (2.1213)
Cylinder distortion	—	0.05 (0.002)
Cylinder head distortion	—	0.05 (0.002)
Piston ring free end gap	Approx. 4.3 (0.17)	3.4 (0.13)
Piston ring end gap	0.45 – 0.60 (0.018 – 0.024)	0.80 (0.031)
Piston ring to groove clearance	0.045 – 0.060 (0.0018 – 0.0024)	—
Piston pin bore	15.002 – 15.008 (0.5905 – 0.5907)	15.030 (0.5917)
Piston pin O.D.	14.995 – 15.000 (0.5904 – 0.5906)	14.980 (0.5898)

CONROD + CRANKSHAFT

Unit: mm (in)

ITEM	STANDARD	LIMIT
Conrod small end I.D.	19.003 – 19.011 (0.7481 – 0.7485)	19.040 (0.7496)
Conrod deflection	—	3.0 (0.12)
Conrod big end side clearance	0.3 – 0.8 (0.0118 – 0.0315)	1.0
Crank web to web width	53.9 – 54.1 (2.12 – 2.13)	—
Crankshaft runout	—	0.05 (0.002)

CLUTCH

Unit: mm (in)

ITEM	STANDARD	LIMIT
Clutch lever play	10 – 15 (0.40 – 0.60)	—
Drive plate thickness	No. 1, 2 2.72 – 2.88 (0.107 – 0.115)	2.42 (0.094)
Drive plate claw width	No. 1, 2 13.85 – 13.96 (0.545 – 0.550)	13.05 (0.514)
Driven plate distortion	—	0.15 (0.006)
Clutch spring free length	39.78 (1.57)	37.8 (1.49)

RADIATOR

ITEM	STANDARD	LIMIT
Radiator cap valve release pressure	95 – 125 kPa (0.95 – 1.25 kgf/cm ² , 13.5 – 17.8 psi)	—

TRANSMISSION

Unit: mm (in) Except ratio

ITEM		STANDARD	LIMIT
Primary reduction ratio		3.368 (84/19)	—
Final reduction ratio		4.167 (50/12)	—
Gear ratios	Low	2.071 (29/14)	—
	2nd	1.687 (27/16)	—
	3rd	1.444 (25/18)	—
	4th	1.200 (24/20)	—
	5th	1.052 (20/19)	—
	Top	0.950 (19/20)	—
Shift fork to groove clearance	No. 1, 2 & 3	0.05 – 0.25 (0.002 – 0.010)	0.45 (0.018)
Shift fork groove width	No. 1, 2 & 3	4.95 – 5.05 (0.195 – 0.200)	—
Shift fork thickness	No. 1, 2 & 3	4.80 – 4.90 (0.190 – 0.193)	—

DRIVE CHAIN

Unit: mm (in)

ITEM		STANDARD	LIMIT
Drive chain	Type	D.I.D 520DM/2	—
	Links	114	—
	20 pin length	—	323.8 (12.7)
Drive chain slack		40 – 50 (1.6 – 2.0)	

CARBURETOR

Unit: mm (in)

ITEM	SPECIFICATION	
	USA, 000	Others
Carburetor type	TMX38S	←
Bore size	38 mm	←
I.D. No.	38F4	38F5
Float height	8.7 ± 1.0 mm (0.34 ± 0.04 in)	
Main jet (M.J.)	#390	#460
Jet needle (J.N.)	6CHY16-62-3rd	6CHY17-62-4th
Pilot jet (P.J.)	#42.5	#42.5
Out-ways (C.A.)	5.0	5.0
Air screw (A.S.)	1 and 1/2 turns out	1 and 1/2 turns out
Throttle cable play	2 – 4 mm (0.08 – 0.16 in) at the throttle grip	

ELECTRICAL

Unit: mm (in)

ITEM	SPECIFICATION		NOTE
Ignition timing	5° B.T.D.C. at 1 000 r/min.		
Spark plug	Type	NGK R69166-B	
	Gap	0.55 – 0.85 (0.022 – 0.026)	
Spark performance	Over B (0.2) at 1 atm.		
Pick-up coil resistance		75 – 125 Ω	R – G
Pick-up peak voltage		3 V and more	⊕ G – ⊖ R
Exciter peak voltage		30 V and more	⊕ R/W – ⊖ B/R
Ignition coil resistance	Primary	0.15 – 0.45 Ω	W/B1 – B/W
	Secondary	12 – 21 kΩ	Plug cap – W/B1
Ignition coil primary peak voltage		210 V and more	⊕ B/W – ⊖ W/B1
Exciter coil resistance		18 – 30 Ω	R/W – R/R

BRAKE + WHEEL

Unit: mm (in)

ITEM	STANDARD		LIMIT
Brake lever adjuster length		11 – 15 (0.4 – 0.6)	—
Rear brake pedal height		0 – 10 (0 – 0.4)	—
Brake disc thickness	Front	3.0 ± 0.2 (0.118 ± 0.008)	2.5 (0.10)
	Rear	4.0 ± 0.2 (0.157 ± 0.008)	3.5 (0.14)
Brake disc runout	Front & Rear	—	0.30 (0.01)
Master cylinder bore	Front	11.000 – 11.043 (0.4331 – 0.4348)	—
	Rear	12.700 – 12.743 (0.5000 – 0.5017)	—
Master cylinder piston diam.	Front	10.957 – 10.994 (0.4314 – 0.4324)	—
	Rear	12.657 – 12.694 (0.4983 – 0.4994)	—
Brake caliper cylinder bore	Front	27.000 – 27.050 (1.0630 – 1.0650)	—
	Rear	27.000 – 27.050 (1.0630 – 1.0650)	—
Brake caliper piston diam.	Front	26.900 – 26.950 (1.0591 – 1.0610)	—
	Rear	26.900 – 26.950 (1.0598 – 1.0617)	—
Brake fluid type		DOT4	
Wheel rim runout	Axial	—	2.0 (0.08)
	Radial	—	2.0 (0.08)

ITEM	STANDARD		LIMIT
Wheel rim size	Front	1.60 × 21	
	Rear	1.05 × 18	
Wheel axle runout	Front	—	0.25 (0.010)
	Rear	—	0.25 (0.010)
Tire size	Front	90/100-21 51M	—
	Rear	100/90-19 57M	—

SUSPENSION

Unit: mm (in)

ITEM	STANDARD	LIMIT	NOTE
Front fork stroke	310 (12.2)	—	
Front fork spring free length	494 ± 2.4 (19.45 ± 0.09)	497 (19.17)	
Front fork damping force adjuster	Rebound	MAX-11 clicks turns back	
	Compression	MAX-9 clicks turns back	
Front fork air pressure	0 kPa (0 kg/cm ² , 0 psi)	—	
Front fork spring rate	4.2 N/mm (0.42 kg/mm)	—	
Rear shock absorber gas pressure	951 kPa (9.8 kg/cm ² , 139.5 psi)	—	
Rear shock absorber spring set length	6.7 (0.26)	—	6.7 mm compressed from spring free length
Rear shock absorber spring rate	50 N/mm (5 kg/mm)	—	
Rear shock absorber damping force adjuster	Rebound	MAX-11 clicks turns back	
	Compression (High speed)	MAX-2 and 1/8 turns back	
	Compression (Low speed)	MAX-8 clicks turns back	
Rear wheel travel	310 (12.6)	—	
Swingarm pivot shaft runout	—	0.3 (0.01)	

TIRE PRESSURE

Front & Rear	70 - 110 kPa (0.7 - 1.1 kg/cm ² , 10 - 16 psi)
--------------	--

FUEL + OIL + COOLANT


ITEM	SPECIFICATION		NOTE
Fuel type	Use only unleaded gasoline of at least 90 pump octane (R/2 + M/2 method)		E-03, 28
	Use only unleaded gasoline of at least 95 octane. (Research method)		The others
Fuel tank capacity	8.0 L (2.1/1.8 US/Imp gal)		
Engine oil type	SUZUKI OO/SUPER 2-CYCLE MOTOR LUBRICANT or equivalent Two Cycle Racing Lubricant		E-03
	MOTUL 800 2T FACTORY LINE OFF ROAD or equivalent Two Cycle Racing Lubricant		The others
Fuel and engine oil mixture ratio	50 : 1		
Transmission oil type	SAE 10W-40		
Transmission oil capacity	Change	750 ml (0.8/0.7 US/Imp qt)	
	Overhaul	800 ml (0.8/0.8 US/Imp qt)	
Front fork oil type	SUZUKI fork oil SS-05 or an equivalent fork oil		
Front fork oil capacity (each leg)	373 ml (12.5/13.4 US/Imp oz)		Outer tube oil quantity
	180 ml (6.08/6.33 US/Imp oz)		Damper rod oil quantity
Engine coolant type	Use an anti-freeze&summer engine coolant compatible with aluminum radiator, mixed with distilled water only, at the ratio of 50 : 50.		
Engine coolant capacity	1.100 ml (1.2/1.0 US/Imp qt)		
Rear shock absorber oil type	SUZUKI rear suspension oil SS-25 or an equivalent suspension oil		
Rear shock absorber oil capacity	380 ml (12.8/13.4 US/Imp oz)		

SPECIAL TOOLS


				
09900-00410 Hexagon wrench set	09900-05107 Snap ring pliers	09900-06108 Snap ring pliers	09900-09003 Impact driver set	09900-20101 Vernier calipers (150 mm)
				
09900-20202 Micrometer (25 - 50 mm)	09900-20203 Micrometer (50 - 75 mm)	09900-20205 Micrometer (0 - 25 mm)	09900-20508 Cylinder gauge set	09900-20502 Dial gauge (1/1 000, 1 mm)
				
09900-20605 Dial gauge (1/100, 10 - 34 mm)	09900-20607 Dial gauge (1/100, 10 mm)	09900-20803 Thickness gauge	09900-25008 Multi circuit tester	09910-32812 Crankshaft installer
				
09910-00611 Universal clamp wrench	09913-60121 Oil seal remover	09920-13120 Crankcase separating tool	09920-20310 Spring hook	09920-53740 Clutch sleeve hub holder
				
09921-20240 Bearing remover set	09923-74511 Bearing puller	09924-64510 Bearing installer set	09924-64521 Bearing installer	09925-18011 Steering bearing installer


 <p>09930-30104 Rotor remover slide shaft</p>	 <p>09930-30113 Flywheel rotor remover</p>	 <p>09930-40113 Rotor holder</p>	 <p>09940-14911 09940-14950 Steering nut socket wrench</p>	 <p>09940-52851 Front fork oil seal installer set</p>
 <p>09941-34513 Bearing installer set</p>	 <p>09940-34581 Attachment F</p>	 <p>09941-53830 Front fork top cap wrench</p>	 <p>09941-54911 Bearing outer race remover</p>	 <p>09913-70210 Bearing installer set</p>
 <p>09900-20701 Magnetic stand</p>	 <p>09900-21304 V-block (100 mm)</p>	 <p>09910-20115 Conrod holder</p>	 <p>09941-74911 Bearing installer</p>	 <p>09900-20905 Tire depth gauge</p>
 <p>09917-50410 Bearing remover</p>				


WIRING DIAGRAM





WIRE, CABLE AND HOSE ROUTING


















SPARK PLUG

- Inspect the spark plug condition, electrode color, carbon deposits, spark plug gap, and washer damage, after removing the spark plug.

NOTE:

Remove the dirt around the spark plug before removing the spark plug to prevent dirt from entering the combustion chamber.

- Inspect the porcelain tip color.



Porcelain tip color	Cause
White (overheated)	<ul style="list-style-type: none"> Hot type spark plug Advanced ignition timing Lean air/fuel mixture Deteriorated fuel
Black (fouled)	<ul style="list-style-type: none"> Cold type spark plug Retarded ignition timing Rich air/fuel mixture Rich oil/gasoline mixture

- Clean the spark plug with a brush or wire and check the spark plug gap with a thickness gauge.

DATA Spark plug gap: 0.55 – 0.65 mm (0.022 – 0.026 in)

DATA Standard Spark plug

NGK	R5918B-8
-----	----------


CAUTION

Changing the spark plug heat range improperly can damage the engine.

Select the spark plug heat range only after adjusting the ignition timing, carburetor setting and oil/gasoline mixture.

- Tighten the spark plug with specified tightening torque after tightening the spark plug temporarily with fingers.

DATA Spark plug: 17.5 N·m (1.75 kgf·m, 12.5 lb-ft)



AIR CLEANER


AIR CLEANER ELEMENT REMOVAL

- Remove the seat.
- Remove the air cleaner box lid.
- Remove the wing nut ①.
- Remove the element ② from the element holder.



WASHING

- Fill a washing pan large enough to hold the element with a non-flammable cleaning solvent ④. Immerse the element in the solvent and wash it.
- Squeeze the element by grasping it to remove excess solvent. Do not twist or wring the element or it will develop cracks.
- Dry the element in a plastic bag, pour in some foam filter oil ⑤ and work the oil into the element.
- Squeeze the element to remove excess oil.



INSTALLATION

- Apply grease to the element base where it contacts the air cleaner box.
- Fit the element onto the element holder.

NOTE:

Fit the projection of the element holder ③ in the hole of the element base ②.



- Install them in the air cleaner box by engaging the projection ④ of the element holder with the hole ⑤ of the cleaner body.

CAUTION

Improper element installation allows dust and dirt to enter the combustion chamber. It can result in piston and cylinder wear.


Be sure to check the element seals properly after installing the elements.



- Install the air cleaner box lid properly as shown.

NOTE:

Running the engine without the air cleaner box lid can vary the carburetion. Do not run the engine without the air cleaner box lid.

**NOTE:**

Follow the instructions below to keep the air cleaner element dry when cleaning the motorcycle.

- Cover the element with vinyl bag.
- Install the seat.
- Cover the inlet hole on the frame cover in order to prevent water from coming into the air cleaner box.
- Do not spray high pressure water to the air cleaner box.



TRANSMISSION OIL

▲ WARNING

Engine oil and exhaust pipes can be hot enough to burn you.

Wait until the oil drain plug and exhaust pipes are cool enough to touch with bare hands before draining oil.

▲ WARNING

New and used oil and solvent can be hazardous. Children and pets may be harmed by swallowing new or used oil or solvent. Continuous contact with used engine oil has been found to cause skin cancer in laboratory animals. Brief contact with used oil or solvent may irritate skin.

- * Keep new and used oil and solvent away from children and pets.
- * Wear a long-sleeve shirt and waterproof gloves.
- * Wash with soap if oil or solvent contacts your skin.

NOTE:

Recycle or properly dispose of used oil and solvent.

TRANSMISSION OIL LEVEL INSPECTION AND REPLENISHMENT

- * Place the motorcycle on level ground and hold the motorcycle vertically.
- * Run the engine for a few minutes and stop it. Wait 3 minutes.
- * Remove the oil level bolt (1). Check that oil comes out of the hole.
- * If oil does not come out of the hole, open oil filler cap (2) and add the specified oil. Tighten the filler cap and oil level bolt firmly and inspect again as above procedure.
- * Tighten the filler cap and oil level bolt firmly.

🔧 Oil level bolt: 5.5 N·m (0.56 kgf-m, 4.0 lb-ft)



TRANSMISSION OIL CHANGE

- * Warm up the engine.
- * Place the motorcycle on the level ground and hold the motorcycle vertically.
- * Remove filler cap and drain plug (1). Drain oil thoroughly.
- * Tighten the drain plug firmly.

🔧 Oil drain plug: 21 N·m (2.1 kgf-m, 14.5 lb-ft)

- * Pour specified amount of SAE 10W-40 motor oil.

DATA Oil change 750 ml (0.8/0.7 US/imp qt)
Overhaul 800 ml (0.9/0.8 US/imp qt)

- * Tighten the filler cap.
- * Run the engine for a few minutes and stop it. Wait a few minutes.
- * Inspect the oil level.



ENGINE COOLANT

ENGINE COOLANT LEVEL CHECK

▲ WARNING

You can be injured by scalding fluid or steam if you open the radiator cap when the engine is hot.

Do not open the radiator cap when the engine is hot. Wait until engine cools.

- Remove the radiator cap (1).
- Check that the engine coolant level is at the bottom of the inlet hole. If not, replenish the radiator with specified engine coolant.
- Tighten the radiator cap securely.

CAUTION

Improperly tightening the radiator cap will prevent the cooling system from reaching the specified operating pressure and will cause coolant overflow.

Tighten the radiator cap until it locks firmly.

NOTE:

- This motorcycle does not have an overflow tank at the end of breather hose. Therefore, engine coolant level may decrease while riding. Check the engine coolant level every time before riding.
- When replenishing engine coolant, be sure to use engine coolant mixed with distilled water at the ratio of 50:50. Adding only water will dilute engine coolant and it may decrease cooling performance.
- If the motorcycle is to be exposed to temperatures below -31°C (-24°F), the percentage of antifreeze should be increased to 55 % or 60 %, according to figure 1.



Antifreeze density	Freezing point
50 %	-31°C (-24°F)
55 %	-40°C (-40°F)
60 %	-55°C (-67°F)




Fig. 1 Engine coolant density-freezing point

ENGINE COOLANT REPLENISHMENT

- Use an anti-freeze and Summer engine coolant which is compatible with aluminum radiator, mixed with distilled water at the ratio of 50:50.

NOTE:

The radiator, cylinder and cylinder head are made of aluminum alloy. Using non-recommended engine coolant may corrode aluminum alloy and may clog the coolant passageways.

▲ WARNING

Engine coolant is harmful if swallowed or if it comes in contact with your skin or eyes.

Keep engine coolant away from children and pets. Call your doctor immediately if engine coolant is swallowed and induce vomiting. Flush eyes or skin with water if engine coolant gets in eyes or comes in contact with skin.

COOLING SYSTEM INSPECTION

Inspect the following items before practice and races.

- Engine coolant leakage
- Radiator base cracks and deterioration
- Radiator mounting condition
- Radiator breather hose condition
- Radiator fin condition



CLUTCH CABLE

Adjust the clutch cable play as follows:

MAJOR ADJUSTMENT

- Loosen locknut ①.
- Turn adjuster ② so the clutch lever has 10 – 15 mm (0.4 – 0.6 in) play at the clutch lever end before pressure is felt.
- Tighten locknut ①.


NOTE Clutch lever play: 10 – 15 mm (0.4 – 0.6 in)



MINOR ADJUSTMENT

- Turn adjuster ③ so the clutch lever has 10 – 15 mm (0.4 – 0.6 in) play at the clutch lever end before pressure is felt.

NOTE Clutch lever play: 10 – 15 mm (0.4 – 0.6 in)



THROTTLE CABLE

⚠ WARNING

Inadequate throttle cable play can cause engine speed to rise suddenly when you turn the handlebars. This can lead to loss of rider control.


Adjust the throttle cable play so that engine speed does not rise due to handlebar movement.

Adjust the throttle cable play as follows:

- Loosen locknut ①.
- Turn adjuster ② so the throttle grip has 2 – 4 mm (0.08 – 0.16 in) play in circumference.
- Tighten locknut ①.

NOTE Throttle cable play ③: 2 – 4 mm (0.08 – 0.16 in)

- Remove the throttle housing cover.



- Apply oil to the throttle cable.
- Apply grease to the throttle cable spool.



FUEL HOSE

- Inspect the fuel hose for damage and fuel leakage. If any defects are found, the fuel hose must be replaced.
- Replace the fuel hose every four years.



FUEL VALVE

- Drain the fuel.
- Disconnect the fuel hose ① and remove the fuel valve ②.

▲ WARNING

Gasoline is highly flammable and explosive.
Keep heat, sparks and flames away from gasoline.



- If the fuel filter is dirty with sediment, fuel will not flow smoothly.
- Clean the fuel filter with compressed air.

CAUTION

The O-ring ③ must be replaced with a new one to prevent fuel leakage.



CYLINDER HEAD, CYLINDER AND PISTON

CYLINDER HEAD

- Remove the cylinder head. (C76-3)
- Remove carbon deposits from the combustion chamber surface.
- Inspect for pinholes, cracks and other damage.



CYLINDER

- Remove the cylinder. (C76-3)
- Remove carbon deposits from the exhaust port.
- Check for scratches and wear on the cylinder sleeve.



PISTON

- Remove the piston. (C76-4)
- Remove carbon deposits from the top surface of the piston.
- Check for scratches, cracks, and wear around the piston bosses.
- Remove minor scuffs with #1 000 – #1 200 sand paper.
- Check piston ring wear. Remove carbon deposits from the piston ring groove.



EXHAUST VALVE

- Remove the exhaust valve assembly. (☞ 6-5)
- Remove carbon deposits from the main exhaust valve, side valve, spacer and exhaust valve guide.
- Check for wear and damage.

NOTE:

If tar drops from the exhaust valve breather hose when the motorcycle is parked, change engine oil brand because some engine oil can accumulate tar in the exhaust valve chamber.



EXHAUST SILENCER

SILENCER INSPECTION AND REPLACEMENT

- Remove the seat and the right frame cover.
- Loosen the silencer mounting bolt and remove the silencer.
- Remove three bolts and extract the black frontal pipe from the aluminum case.

- Inspect the glass wool ① for clogging with carbon deposit or tar.
- Replace the glass wool ① with a new one if necessary.

SILENCER REASSEMBLY

- Fit the glass wool ① and the black frontal pipe to the aluminum case.
- Tighten three bolts.

NOTE:

To seal between the black frontal pipe flange and the aluminum case, apply SUZUKI BOND to the contact area of the flange.

- ☞ 99104-31140: SUZUKI BOND "1207B" (USA)
- ☞ 99000-31140: SUZUKI BOND "1207B" (Others)




DRIVE CHAIN AND SPROCKETS

DRIVE CHAIN SLACK

- Place the motorcycle on the side stand.
- Inspect the drive chain slack at the middle point between the two sprockets.

DATA Drive chain slack: 40 – 50 mm (1.6 – 2.0 in)



DRIVE CHAIN ADJUSTMENT

- Loosen the axle nut ①.
- Loosen the locknuts ② and adjust the drive chain slack to the specification by turning the adjusters ③. Make sure that the right and left adjuster plates ④ are at the same position on scales ⑤.
- With the adjusters ③ held in position, tighten the locknuts ②.
- Push the adjuster plates ④ to the adjusters ③ and tighten the axle nut ①.




U Axle nut: 100 N·m (10.0 kgf-m, 72.5 lb-ft)

- Tighten the locknut ②.

NOTE:

Pull the upper drive chain tight and lock it by placing a bar between the drive chain and rear sprocket while tightening the axle nut. This will help prevent the chain adjusters from loosening.



20TH PITCH LENGTH

- Pull the drive chain tight and measure the 20th pitch length.

DATA Service Limit: 323.8 mm (12.7 in)

DRIVE CHAIN LUBRICATION

- Remove the chain clip and master link from the drive chain and remove the drive chain.


NOTE:

Be careful not to bend the chain clip.

- Inspect for wear and damage of the drive chain and replace it if necessary.



- Clean the drive chain with non-flammable cleaning solvent.
- Do not use gasoline to clean the drive chain.
- Dry the drive chain.
- Apply Suzuki Chain Lube or an equivalent to the link plates and rollers.




- Reassemble the drive chain.

NOTE:

Reassemble the drive chain clip so the *self* end faces opposite the direction of rotation.

- Adjust the drive chain slack.



SPROCKET INSPECTION

- Inspect the engine sprocket and rear sprocket for wear and cracks. Replace the sprockets as necessary.

NOTE:

When replacing a worn sprocket, it is likely that the drive chain will need to be replaced as well.



DRIVE CHAIN GUIDE, BUFFER, TENSIONER ROLLER

DRIVE CHAIN GUIDE

- Inspect the drive chain guide ① for bends and damage.

NOTE:

The drive chain can hit a bent guide causing noise and drive chain wear.

- Inspect the chain guide deflexion ② for wear.



DRIVE CHAIN GUIDE BUFFER

- Inspect the drive chain guide buffer (3) for wear and cracks.

NOTE:

The drive chain can touch the swingarm directly if the chain guide buffer is worn out. This will cause drive chain and swingarm damage.

DRIVE CHAIN TENSIONER ROLLER

- Inspect the drive chain tensioner rollers (4) for wear.
- Inspect the tensioner roller bolts for tightness.

 Drive chain tensioner roller bolt:

31 N·m (3.1 kgf-m, 22.5 lb-ft)

**BRAKES****BRAKE FLUID LEVEL**

- Inspect the brake fluid level in both front and rear reservoirs. If the brake fluid level is lower than LOWER mark (5), replenish the reservoir with the specified brake fluid to the UPPER level. Inspect brake pad wear and brake fluid leakage if the brake fluid level decreases.

 Brake fluid: DOT 4

▲ WARNING

Brake fluid can be hazardous to humans and pets. Brake fluid is harmful or fatal if swallowed, and harmful if it comes in contact with your skin or eyes.

Keep brake fluid away from children. Call your doctor immediately if brake fluid is swallowed, and induce vomiting. Flush eyes or skin with water if brake fluid gets in eyes or comes in contact with skin.

▲ WARNING

The use of any fluid except DOT4 brake fluid from a sealed container can damage the brake system and lead to an accident.

Use only DOT4 brake fluid from a sealed container. Never use or mix different types of brake fluid.

CAUTION

Spilled brake fluid can damage painted surfaces and plastic parts.

Be careful not to spill any fluid when filling the brake fluid reservoir. Wipe spilled fluid up immediately.




BRAKE PAD

- Inspect the brake pads for wear. If the brake pads are worn, replace them with new ones. (☞ 15-5)

NOTE:

- * Pump the brake lever/pedal several times to restore the brake pads after replacing the brake pads.
- * Replace both right and left pads together when replacing the brake pads.



FRONT BRAKE LEVER ADJUSTMENT

Adjust the brake lever position as follows:

- Loosen locknut ①.
- Turn in or out adjuster ② to obtain the proper brake lever position.
- The standard adjuster length ③ is from 11 mm to 15 mm.
- Tighten the locknut ①.

DATA Adjuster length ③: 11 – 15 mm (0.4 – 0.6 in)



BRAKE PEDAL HEIGHT ADJUSTMENT

Adjust the rear brake pedal height as follows:

- Loosen locknut ①.
- Adjust the brake pedal height ② by turning the adjuster ③ to locate the pedal 0 – 10 mm (0 – 0.3 in) below the top face of the footrest.
- Tighten locknut ①.

DATA Brake pedal height ②: 0 – 10 mm (0 – 0.3 in)



FRONT FORK

- Move the front fork up and down several times and inspect for smooth movement.
- Inspect for damage and oil leaks.
- Inspect the bolts and nuts for tightness.
- Place a stand under the chassis tube to lift the front wheel off the ground.



- Remove the air bleed screw and equalize the air pressure in the front forks to atmospheric pressure.
- Retighten the air bleed screw.



REAR SUSPENSION

- Move the rear suspension up and down several times and inspect for smooth movement.
- Inspect for damage and oil leaks.
- Inspect the bolts and nuts for tightness.



WHEELS AND TIRES

WHEEL RIM

- Inspect the wheel bearing for rattles. Replace the bearings if necessary. (C7-14-4)
- Inspect the wheel rim runout. (C7-14-4)




SPOKE NIPPLE AND RIM LOCK

- Inspect the spokes for tension by squeezing the spoke nipples.
- Retighten the spoke nipples with a spoke nipple wrench so as all spokes have same tension.

CAUTION

Improperly tightening the spoke nipples can damage the wheel.

Tighten the spoke nipples less than 1/2 turn at a time. Inspect the spoke tension and then retighten the spoke nipple.



- Inspect the rim lock ① for tightness.



TIRE PRESSURE

- Inspect front and rear tire pressure.

DATA Tire pressure (cold): 70 ~ 110 kPa
(0.7 ~ 1.1 kgf/cm², 10 ~ 16 psi)



STEERING

- Inspect the steering by moving the front fork up and down, and right and left. If the steering has play or binds, inspect steering stem nut tightness and steering bearings. (P.18-20)



LUBRICATION

Apply grease or oil to the moving parts to increase durability and prevent wear.

No.	ITEM	LUBRICANT	FREQUENCY	COMMENTS
①	Inner cable ends, lever	A	Pre-race and between every race	Run oil through cables until it exits the lower end. Lube the cable ends where they pivot.
②	Throttle grip, throttle housing, cable	A	Pre-race	Lightly grease the inside of throttle spool. Keep free from dirt.
③	Rear brake pedal	C	Pre-race	Grease the brake pedal pivot.
④	Swingarm	C	Every 3 races/More often according to conditions	Clean and pack the bearings. Keep seals fresh. Grease the seals.
⑤	Rear suspension linkage pivot points	C	Every 1 race/More often according to conditions	Clean and pack the bearings. Keep seals fresh. Grease the seals.
⑥	Steering stem bearings	C	Every 5 races/More often according to conditions	Clean and pack the bearings. Keep seals fresh.
⑦	Starter shaft	A	Pre-race	Lightly oil the plunger shaft.
⑧	Drive chain	B	Pre-race and between every race	Keep chain thoroughly lubed at all times. Always check wear and alignment.

The following materials are necessary:

- A. Lightweight oil such as WD-40 or penetrating oil
- B. Aerosol type Chain Lube.
- C. SUZUKI SUPER GREASE "A" or Water-proof wheel bearing grease.






Follow the schedule closely. The disassembly necessary to lubricate many components is in itself valuable preventative maintenance. It allows you to inspect for wear, fatigue, adjustment and fastener tightness and it allows you to clean out the grit which otherwise cannot be gotten out.

TIGHTENING TORQUE

PART	N·m	kgf·m	lb·ft
Cylinder head nut	25	2.5	18.0
Magneto rotor nut	35	3.5	25.5
Cylinder nut	25	2.5	18.0
Crankcase bolt	10	1.0	7.5
Clutch sleeve hub nut	70	7.0	51.0
Primary drive gear bolt	70	7.0	51.0
Spark plug	17.5	1.75	12.5
Transmission oil drain plug	21	2.1	14.5
Transmission oil level bolt	5.5	0.55	4.0
Water pump drain plug	5.5	0.55	4.0
Handbar clamp bolt	25	2.5	18.0
Front fork upper clamp bolt (right and left)	23	2.3	16.5
Front fork lower clamp bolt (right and left)	23	2.3	16.5
Steering stem head nut	100	10.0	72.5
Front fork center bolt	70	7.0	51.0
Fork cylinder inner rod locknut	23	2.3	16.5
Front fork cap bolt	35	3.5	25.5
Fork cylinder compression damper unit	30	3.0	21.5
Master cylinder mounting bolt (front)	10	1.0	7.0
Master cylinder mounting bolt (rear)	10	1.0	7.0
Brake hose union bolt (front and rear)	33	2.3	16.5
Brake caliper mounting bolt (front)	25	2.5	18.9
Brake pad mounting bolt (front and rear)	17.5	1.75	13.2
Brake caliper axle bolt (For bracket, front and rear)	13	1.3	9.5
Brake caliper axle bolt (For caliper, front)	23	2.3	16.5
Brake air bleeder valve (front and rear)	6.0	0.6	4.5
Brake pedal boss bolt	29	2.9	21.0
Disc plate bolt	10	1.0	7.0
Front axle holder bolt	18	1.8	13.0
Front axle nut	35	3.5	25.5
Engine plate nut	43	4.3	31.0
Engine mounting nut (upper)	44	4.4	32.0
Engine mounting nut (front)	44	4.4	32.0
Engine mounting nut (lower)	44	4.4	32.0
Rear axle nut	100	10.0	72.5
Rear sprocket nut	30	3.0	21.5
Drive chain tensioner roller bolt	31	3.1	22.5
Spoke nipple	4.0	0.4	3.0
Rear swingarm pivot nut (engine mounting)	70	7.0	50.5
Rear shock absorber mounting nut (upper and lower)	60	6.0	43.5
Rear cushion lever nut	80	8.0	56.0
Rear cushion rod nut	80	8.0	56.0

For other bolts and nuts not listed in the table, refer to this chart.

Bolt Diameter (mm)	Conventional or "4" marked bolt		"7" marked or crown headed bolt	
	N·m	kgf·m	N·m	kgf·m
4	2.0	0.2	2.0	0.2
5	3.0	0.3	5.0	0.5
6	5.0	0.6	10.0	1.0
8	13.0	1.3	23.0	2.3
10	29.0	2.9	50.0	5.0
12	45.0	4.5	85.0	8.5
14	65.0	6.5	135.0	13.5
16	105.0	10.5	210.0	21.0
18	190.0	19.0	240.0	24.0



SAMPLE

TROUBLESHOOTING

CONTENTS

TROUBLESHOOTING	3-2
ENGINE	3-2
CHASSIS	3-5

SAMPLE

TROUBLESHOOTING ENGINE

Complaint	Possible Cause	Remedy
Engine does not start or hard to start	Fuel deterioration No fuel flow to the carburetor <ul style="list-style-type: none"> • Fuel valve clogged • Fuel hose clogged • Fuel tank cap breather hose clogged • Carburetor float valve malfunction Too rich air/fuel mixture in combustion chamber Incorrect ignition timing No spark at spark plug Low compression <ul style="list-style-type: none"> • Piston ring worn or stuck • Cylinder worn • Air leak from cylinder gasket • Air leak from crankshaft oil seal 	Replace Clean Clean or replace Clean Replace Scavanga Adjust 13-3 Replace Replace Replace Replace
Engine stalls	Fuel deterioration Fouled spark plug Fuel hose clogged Air cleaner clogged Carburetor jets clogged Low compression <ul style="list-style-type: none"> • Piston ring worn or stuck • Cylinder worn • Air leak from cylinder gasket • Air leak from crankshaft oil seal Incorrect ignition timing	Replace Clean or replace Clean or replace Clean or replace Clean Replace Replace Replace Replace Adjust
Insufficient power	Fuel deterioration Brake dragging Exhaust pipe cracked or clogged with carbon Exhaust valve maladjustment Exhaust valve carbon deposits Air cleaner element clogged Carburetor jets clogged Incorrect fuel level in carburetor Incorrect spark plug gap Cylinder or piston ring worn Reed valve malfunction Incorrect ignition timing	Replace Adjust Replace or clean Adjust Clean Clean or replace Clean or replace Adjust Adjust or replace Replace Replace Adjust

Complaint	Possible Cause	Remedy
Engine runs poorly in low speed range	Exhaust valve maladjustment Wide spark plug gap Carburetor air screw maladjustment Incorrect carburetor fuel level Improper jet needle size Incorrect ignition timing CDI unit malfunction Ignition coil damage Magneto malfunction Magneto short circuit	Adjust Adjust or replace Adjust Adjust Replace Adjust Replace Replace Replace
Engine runs poorly in high speed range	Narrow spark plug gap Incorrect carburetor fuel level Retarded ignition timing CDI unit malfunction Ignition coil damage Air cleaner element clogged Magneto short circuit Exhaust pipe cracked Exhaust valve malfunction Piston ring stuck	Adjust or replace Adjust Adjust Replace Replace Clean or replace Replace Replace Clean, adjust or replace Replace
Exhaust valve does not work	Carbon deposits on exhaust valve Exhaust valve damage Governor damage Exhaust valve shaft damage Valve spring damage Exhaust valve breather hose clogged	Clean Replace Replace Replace Replace Clean
Spark plug does not ignite	Ignition coil malfunction Spark plug malfunction Magneto malfunction CDI unit malfunction Wide spark plug gap Engine stop switch malfunction	Replace Replace Replace Replace Adjust Repair or replace
Carbon deposits on spark plug porcelain	Too rich air/fuel mixture Too rich oil/gasoline mixture Improper spark plug heat range	Adjust Adjust Replace
Spark plug electrode damage	Improper spark plug heat range Overheating Incorrect ignition timing Loose spark plug Too lean air/fuel mixture	Replace ①③-1 Adjust Tighten Adjust

Complaint	Possible Cause	Remedy
Overheating	Low engine coolant level Engine coolant leak Too lean air/fuel mixture Incorrect ignition timing Water pump malfunction Cylinder head carbon deposits Exhaust pipe carbon deposits Improper spark plug heat range Fuel deterioration Clutch slipping Radiator cap loose Radiator fins damaged	Replenish Repair Adjust Adjust Adjust or replace Clean Clean or replace Replace Replace Adjust or replace Tighten Repair or replace
Excessive coolant level decrease	Radiator hose cracked or damaged Loose radiator hose connection Radiator cracked or damaged Water pump cover mating surface damage Water pump cover crack Water pump cover gasket damage Water seal wear or damage Radiator cap seal damage Incorrect radiator cap valve pressure Cylinder or cylinder head cracked Cylinder or cylinder head O-rings damage	Replace Repair Repair or replace Replace Replace Replace Replace Replace Replace Replace Replace
Clutch does not disengage	Clutch lever play misadjustment Clutch spring damage Clutch plates distortion Tip of clutch release camshaft worn	Adjust Replace Replace Replace
Clutch slipping	Clutch cable play misadjustment Weakened clutch spring Clutch pressure plate wear Clutch plates distortion Clutch plates worn Tip of clutch release camshaft worn	Adjust Replace Replace Replace Replace Replace
Transmission does not shift	Gearshift cam damage Gearshift fork distortion Gearshift pawl wear	Replace Replace Replace
Transmission gears jump out	Gearshift fork groove wear or damage Gearshift fork distortion or wear Gearshift cam stopper damage Transmission gear claw damage	Replace Replace Replace Replace
Gearshift lever does not return	Weakened gearshift return spring Gearshift lever sticking	Replace Repair or replace

CHASSIS

Complaint	Possible Cause	Remedy
Heavy handling	Steering stem nut overtightened Steering head bearings damaged or rusted Steering stem distortion	Adjust Replace Replace
Front wheel wobbling	Loose spoke nipples Wheel distortion Front wheel bearing damage Incorrect axle tightening torque	Adjust Replace Replace Retighten
Rear wheel wobbling	Loose spoke nipples Wheel distortion Rear wheel bearing damage Swingarm pivot bearing damage Incorrect axle tightening torque Incorrect swingarm tightening torque	Adjust Replace Replace Replace Retighten Retighten
Soft front suspension	Weakened spring Low oil level Low fork oil viscosity Damping force maladjustment Damping valve malfunction Standard spring too soft	Replace Replenish Replace Adjust Replace * Use optional spring
Hard front suspension	High fork oil level High fork oil viscosity Damping force maladjustment Finner tube distortion Standard spring too hard	Adjust Replace Adjust Replace * Use optional spring
Soft rear suspension	Weakened spring Damping force maladjustment Low gas pressure Standard spring too soft	Replace Adjust Adjust * Use optional spring
Hard rear suspension	Damping force maladjustment Damper rod distortion Rear suspension pivoting portion out of grease Standard spring too hard	Adjust Replace Lubricate * Use optional spring
Poor braking	Brake pads worn Improper air bleeding Dirty pads and disc Brake fluid leak	Replace Bleed air Clean Repair
Brake noise	Brake pads worn Brake disc worn Dirty brake pads and disc	Replace Replace Clean

* Optional stiffer and softer springs are available.

MACHINE TUNING

CONTENTS

CARBURETOR TUNING	4-2
PRINCIPLES OF CARBURETOR TUNING	4-2
CARBURETOR TUNING IN PRACTICE	4-6
FRONT FORK TUNING	4-9
COMPRESSION DAMPING FORCE ADJUSTMENT	4-9
REBOUND DAMPING FORCE ADJUSTMENT	4-9
OIL QUANTITY MINOR ADJUSTMENT	4-10
OIL CHANGE (Only for outer tube oil chamber)	4-11
SPRING CHANGE	4-13
FRONT FORK TUNING PROCEDURE	4-15
REAR SUSPENSION TUNING	4-16
COMPRESSION DAMPING FORCE ADJUSTMENT	4-16
REBOUND DAMPING FORCE ADJUSTMENT	4-16
SPRING PRE-LOAD ADJUSTMENT	4-17
REAR SUSPENSION TUNING PROCEDURE	4-18
SUSPENSION BALANCE	4-20
BALANCE TEST	4-20
BALANCING TIPS	4-20

CARBURETOR TUNING

The carburetor of your motorcycle was carefully selected after extensive testing. You will find that the carburetor will function smoothly under many varied operating conditions. For best results we recommend that the adjustments and carburetor jetting be left "as is" from the factory.

Some riders may operate their motorcycle under extreme operating conditions such as; very high altitudes or extreme cold and hot temperatures. In these circumstances the jetting of the carburetor or other adjustments may need to be altered slightly. Riders who are not familiar with the operation and jetting procedures of the MIKUNI carburetor should have their local authorized Suzuki dealer perform these alterations. Mechanically experienced riders can alter the carburetor settings based on the following information and specifications.

Carburetor Specifications E-28


Bore	38 mm
Main jet	#160
Jet needle	6CHY17-62-4th
Pilot jet	#42.5
Air screw	1 and 1/2 turn out
Float height	6.7 ± 1.0 mm (0.34 ± 0.04 in)

Setting parts	Parts No.
Main jet #300	09491-78005
Main jet #410	09491-82007
Main jet #430	09491-86002
Main jet #490	09491-58001

PRINCIPLES OF CARBURETOR TUNING


CARBURETOR COMPONENTS AND FUNCTIONS

The carburetor consists of a number of parts as shown below. The asterisk (*) marked parts are precisely machined, which meter the intake air (oxygen) and fuel so that the air/fuel mixture ratio is controlled accurately. They can be divided by three operation-related groups; pilot (slow) system, intermediate system and main system, and they achieve their functions in each corresponding throttle opening range. It is necessary to have a full understanding of them for proper carburetor tuning.



- | | |
|------------------------|------------------------|
| 1. Top cap | 9. * Air screw |
| 2. Spring | 10. * Main jet |
| 3. Cable holder | 11. * Pilot jet |
| 4. * Clip | 12. Needle valve ass'y |
| 5. * Jet needle | 13. Float |
| 6. Throttle valve | 14. Float chamber |
| 7. Starter knob | 15. Holder |
| 8. Throttle stop screw | |

As shown below, each tuning part is located between the air/fuel passage and has its own air/fuel mixture adjustable range in terms of the throttle valve opening. The chart indicates that the carburetor can supply correct air/fuel mixture to the engine in any range because of the overlapping adjustable range of the each part.



① MAIN SYSTEM ② INTERMEDIATE SYSTEM ③ PILOT SYSTEM

When performing carburetor tuning, first find out in what throttle opening range an improper air/fuel mixture is supplied, by checking the color of exhaust smoke, spark plug, throttle response, power, etc. Second, replace or adjust the part(s) related to the throttle opening range by referring to the following instructions. The sizes related to in the illustrations are those of standard setting.

PILOT JET




The pilot jet meters the fuel supplied to the pilot system. Each jet size is indicated by a number. Larger number means a larger bore diameter and fitting a larger numbered pilot jet enriches the air/fuel mixture.

AIR SCREW



The air screw is located in the inlet air passage and meters the air for the slow system. As it has a right-hand thread, tightening it makes the passage narrower, allowing less amount of intake air to flow and resulting in richer air/fuel mixture. Air flow adjustment is effective within a range of 1/2 – 2 turns out.

NEEDLE CLIP POSITION



The jet needle is linked to the throttle valve by means of the needle clip. Its lower part is tapered and it has five grooves cut in the upper part where the needle clip fits.

To adjust the air/fuel mixture with the jet needle, change position of the needle clip which is set in the 4th groove. The lower groove the clip is moved to, the higher the jet needle rises and the larger the clearance with the needle jet becomes, resulting in a richer air/fuel mixture ratio.

The needle clip position can be changed by half to fine-tune the setting as following manner.

- Replace the cable holder with the included holder and included red washer.


The two holders are different in color. The standard holder is gray. The included holder is yellow. The included holder and red washer must be installed as a set.

- Change the red washer location from over the needle clip to under the needle clip. This change will move the needle position by half to the richer side. The original position of red washer is over the needle clip.

By replacing the jet needle with the optional one, it is possible to perform the same setting as describing above. Change the jet needle from 6CHY17 type to 6CHY16 type. This change will move the needle position by half to the richer side. 6CHY16 type jet needles are available as optional parts. For example, "6CHY17-62-4th" with the red washer installed under the needle clip is the same setting as "6CHY16-62-4th".

	Needle type and clip position
Lean ↓ Rich	6CHY17-62-2nd
	6CHY16-62-2nd
	6CHY17-62-3rd
	6CHY16-62-3rd
	6CHY17-62-4th

JET NEEDLE



NEEDLE NUMBER

6CHY17-62-4th

O.D. 2.62 mm

Changing the needle itself controls air/fuel mixture ratio particularly on lower mid-throttle opening. (Size 62 indicates that O.D. is 2.62 mm) The smaller the O.D., the richer the air/fuel mixture becomes.

EX.

Needle Number	O.D.
6CHY17-64	2.64 mm
6CHY16-64	
6CHY17-63	2.63 mm
6CHY16-63	
6CHY17-62	2.62 mm
6CHY16-62	
6CHY17-61	2.61 mm
6CHY16-61	
6CHY17-60	2.60 mm
6CHY16-60	

MAIN JET




The main jet, like the slow jet, meters fuel flow. Each jet size is indicated by a number. Larger number means a larger bore diameter and fitting a larger number main jet enriches the air/fuel mixture.

THROTTLE STOP SCREW

The throttle stop screw determines the full close position of the throttle valve and should be adjusted in the following procedures.

- Loosen the throttle stop screw locknut.
- Adjust the throttle stop screw as follows:
 - * Turn in (to raise the throttle valve).
 - * Turn out (to lower the throttle valve).
- With the throttle stop screw held immovable, tighten the locknut to lock the screw.



① Throttle stop screw
② Locknut

NOTE:

Opening the throttle valve slightly by adjusting the throttle stop screw may often improve hesitation problem due to lack of mixture on returning the throttle.


If engine idling is desired, turn in the throttle stop screw to raise the throttle valve in the above procedures.

DATA Throttle valve opening position

Standard	After touching the throttle stop screw to the throttle valve, turn in the stop screw 1/4 – 3/4 turn to raise the throttle valve.
----------	--

CAUTION

Too high an engine idle may cause driveability failure such as lack of engine braking and poor deceleration during brake application.




CARBURETOR TUNING IN PRACTICE

In the previous section, basic principles of carburetor tuning have been discussed. Described in this section are the bases for carburetor tuning required when coping with variations in air (oxygen) concentration.

VARIATION IN AIR (OXYGEN) CONCENTRATION AND CARBURETOR CONDITIONS

As the air, affected by the temperature, altitude and humidity, gets expanded or compressed, air (oxygen) concentration varies accordingly. Each of these three factors affects the air in different ways, and the following graphs show their effects respectively in terms of the oxygen concentration.



In the above graphs, oxygen concentration is graduated on the vertical axis while the temperature, altitude and humidity are on the horizontal axis respectively. Oxygen concentration is set 100 % under the conditions of 20 °C (68 °F), 0 m (0 ft) and 60 % humidity. The standard carburetor setting is chosen to obtain the best engine performance under these conditions.

The graph at the left shows that the oxygen concentration changes about 10 % in the 0 °C (32 °F) to 40 °C (104 °F) temperature difference, the one in the center shows about 20 % change in the 0 to 2,000 m (6,562 ft) altitude difference and the one at the right shows about 5 % change in the 0 to 100 % humidity difference. As for humidity, its normal range is from 20 to 95 %. Therefore the possible effect of humidity on the oxygen concentration is so little that it can be disregarded. Consequently, we can say that the oxygen concentration varies by as much as 20 % depending on the temperature and altitude under normal riding conditions. On the other hand, different from the air, the fuel (gasoline) hardly changes in volume even when such environmental conditions change. Therefore, increase in oxygen concentration will make the air/fuel mixture richer and decrease will make it lean.

As the carburetor mixes gasoline and air, which are metered by each jet in varying proportions to suit throttle opening, the air/fuel mixture is affected if the air concentration itself varies as described above. Then proper engine power output can not be attained and, should the mixture become too lean, a piston seizure may result. To compensate for such change in the air concentration, it is required to carry out carburetor tuning beforehand. This requirement applies to all models of motorcycles and ATVs if they are used in areas where temperature and altitude range widely. The next section describes the procedure of the above tuning in detail.

JUDGING AIR/FUEL MIXTURE

For proper carburetor tuning, it is necessary to know how to judge the air/fuel mixture made in the carburetor; whether too rich, too lean or properly mixed. Given below are the symptoms observed when the engine is not supplied with the proper air/fuel mixture ratio from the carburetor. Check each item as reference for judging the air/fuel mixture condition.

When air/fuel mixture is too rich

- 1) The engine noise is dull and intermittent.
- 2) The engine condition becomes worse when the bypass is applied.
- 3) The engine condition becomes worse as it is warmed up.
- 4) The engine condition improves when the air cleaner is removed.
- 5) The spark plug is fouled with carbon (wet and oily).
- 6) The exhaust gas produces heavy smoke.

When air/fuel mixture is too lean

- 1) The engine overheats.
- 2) The engine condition improves when the bypass is applied.
- 3) Acceleration is poor.
- 4) The spark plug is burned white.
- 5) The speed of the engine fluctuates and lack of power is noticed.
- 6) Detonation and pinging are experienced.

TUNING PROCEDURE


The following indicates the correct tuning procedure for this motorcycle. Understand the procedure by first riding the motorcycle where it will be used and adjust the engine to the best condition after judging the air/fuel mixture.

Carburetor standard setting


E-28

- Main jet: #160
- Jet needle: 6CHY17-62-4th
- Pilot jet: #42.5
- Air screw: 1 and 1/2 turns out

INCLUDED PARTS AND OPTIONAL PARTS**Main jet**

Air/fuel mixture	SIZE	P/NO
Lean 	#350	09491-70011
	#360	09491-72011
	#370	09491-74003
	#380	09491-76003
	* #390	09491-78005
	#400	09491-80010
	* #410	09491-82007
	#420	09491-84008
	* #430	09491-86002
	#440	09491-88001
	#450	09491-90005
	#460	09491-92002
	#470	09491-94004
	#480	09491-96001
* #490	09491-98001	
Rich	#500	09491-10001

Pilot jet

Air/fuel mixture	SIZE	P/NO
Lean 	#25	09492-25011
	#27.5	09492-27011
	#30	09492-30014
	#32.5	09492-32010
	#35	09492-35021
	#37.5	09492-37003
	#40	09492-40028
	#42.5	09492-42023
	#45	09492-45034
	#47.5	09492-47022
	Rich	#50

Cable holder and washer

ITEM	P/NO	Color
Cable holder	* 13518-36F20	Yellow
Washer	* 13394-36F20	Red

The cable holder and washer must be used as a set.

ENGINE REMOVAL AND INSTALLATION

REMOVAL

- Drain transmission oil. (2-9)
- Drain engine coolant. (12-3)
- Remove the seat (1).




- Turn the fuel valve lever to the 'OFF' position and disconnect the fuel hose (2).



- Remove the fuel tank mounting bolts (3), left and right.
- Remove the fuel tank by unhooking the band (4) from the hooked part.





SPECIFICATIONS

DIMENSIONS AND DRY MASS

Overall length.....	2 145 mm (84.4 in)
Overall width.....	840 mm (33.1 in)
Overall height.....	1 275 mm (50.2 in)
Wheelbase.....	1 450 mm (57.1 in)
Ground clearance.....	350 mm (13.8 in)
Seat height.....	950 mm (37.4 in)
Dry mass.....	87 kg (192 lbs)

ENGINE

Type.....	Two-stroke, liquid-cooled
Intake system.....	Crankcase reed valve
Number of cylinders.....	1
Bore.....	54.0 mm (2.126 in)
Stroke.....	54.5 mm (2.148 in)
Piston displacement.....	124 cm ³ (7.6 cu. in)
Corrected compression ratio.....	8.79 : 1 (Ex. valve open/Ex. valve close)
Carburetor.....	MIKUNI TMX38S single
Air cleaner.....	Polyurethane foam element
Starter system.....	Primary kick
Lubrication system.....	Fuel/oil premixture of 30 : 1

TRANSMISSION

Clutch.....	Wet multi-plate type
Transmission.....	6-speed constant mesh
Gearshift pattern.....	1-down, 5-up
Primary reduction ratio.....	3.369 (64/19)
Final reduction.....	4.167 (50/12)
Gear ratios, Low.....	2.071 (29/14)
2nd.....	1.687 (27/16)
3rd.....	1.444 (26/18)
4th.....	1.200 (24/20)
5th.....	1.052 (20/19)
Top.....	0.950 (19/20)
Drive chain.....	D.I.D S20DMA2, 114 links

SPARE PARTS LIST

ITEM	PART NAME	PART NUMBER	Q'TY
1	CARBURETOR ASSY	13200-36F50	1
2	PARTS SET, SPARE	19900-36F50	1
3	SET, CARBURETOR SETTING PARTS	09190-00069	1
4	O-RING, CYLINDER HEAD No. 1	11147-27C11	2
5	O-RING, CYLINDER HEAD No. 2	11146-27C11	2
6	GASKET, CYL COVER, No. 1	11233-27C33	2
7	GASKET, CYL COVER, No. 2	11238-36E01	1
8	GASKET, CYLINDER	11241-36F00	2
9	GASKET, CRANKCASE	11481-36F20	1
10	GASKET, CLUTCH COVER	11482-36F00	1
11	GASKET, MAGNETO COVER	11483-36E11	1
12	O-RING, CLUTCH COVER OUTER	11484-36E10	1
13	PISTON COMP	12110-36F00-0F0	1
14	RING, PISTON	12141-36F00	2
15	PIN, PISTON	12151-01B41	1
16	PISTON	12111-36F00	1
17	PIN, KNOCK	09207-02008	1
18	O RING, EXHAUST PIPE	14171-36E00	2
19	LEVER, BRAKE	57310-57F00	1
20	LEVER, CLUTCH	57621-28C40	1
21	BEARING, PISTON PIN	09283-15010	1
22	O RING, SPROCKET SPACER	09280-20006	2
23	CIRCLIP, PISTON PIN	09381-15001	2

OPTIONAL PARTS
REAR SPROCKET

	PARTS No.	NUMBER OF TEETH	COMMENTS
REAR SPROCKET	64511-14D60	48	112 L
	64511-28E00	49	112 L or 114 L
	64511-40Z61	51	114 L

▲ WARNING

Failure to follow these safety precautions may increase your risk of injury:

- Wear a helmet, eye protection, and bright protective clothing.
- Don't ride after consuming alcohol or other drugs.
- This owner's service manual contains important safety information. Please read it carefully.

SAMPLE



Part No. 99011-38F53-01A
June, 2003 © EN
Printed in Japan

K4